



PARTS LIST OF MAXZSP 60

ITEM#	DESCRIPTION	PART#(60)	ITEM#	DESCRIPTION	PART#(60)
1	Drag Knob Assembly	1530017	29	Rotor	1537767
2	Retainer Ring	1085295	30	Screw	1126451
3	Key Washer	1108878	31	Bearing Retainer	1126352
4	Eared Washer	1131685	32	Washer	1536768
5	Washer	1131686	33	Bearing 8*14*4	1108910
6	Spool	1537763	34	Bearing Holder	1257344
7	Spool Assembly	1537764	35	Clutch Assembly	1257345
8	Washer (T=0.5)	1536766	36	Pinion	1536776
9	Click Gear	1536767	37	Handle Screw	1537733
10	Main Shaft	1131720	38	Body	1537768
11	Nut Set Screw	1141435	39	Slider Retainer	1126453
12	Rotor Nut	1257336	40	Screw	1188428
13	Bail Arm Screw	1529197	41	Slider	1131735
14	Bail Holder	1537765	42	Slider Screw	1277072
15	Bushing	1188283	43	Rear Cover	1530086
16	Screw	1381382	44	Oscillation Gear	1131736
17	Bail Arm	1537766	45	Reduction Gear	1224016
18	Bearing 5*8*2.5	1112125	46	Drive Gear	1536777
19	Washer	1110165	47	Washer	1257352
20	Line Roller	1141495	48	Body Cover	1537769
21	Brass Bushing	1279727	49	Screw	1085599
22	Bail Assembly	1530022	50	Screw	1536770
23	Screw	1092845	51	Handle Rivet Assembly	1530088
24	Bail Arm Cover	1530023	52	Handle Knob	1530030
25	Trip Spring	1348016	53	Screw	1119121
26	Trip Linkage	1252713	54	Handle Knob Cover	1529198
27	Trip Bushing	1128143	55	Handle Assembly	1537770
28	Trip Bar	1288117			