



PARTS LIST OF MAXXSP30/40

ITEM#	DESCRIPTION	PART#(30)	PART#(40)	ITEM#	DESCRIPTION	PART#(30)	PART#(40)
1	Drag Knob Assembly	1529993	1529993	31	Washer	1114764	1114764
2	Retainer Ring	1085295	1085295	32	Bearing 7*13*4	1252717	1252717
3	Key Washer	1085296	1085296	33	Bearing Holder	1280475	1280475
4	Eared Washer	1085297	1085297	34	Clutch Assembly	1102144	1102144
5	Washer	1085298	1085298	35	Pinion	1536764	1536765
6	Spool	1529994	1530007	36	Clutch Spring	1252716	1252716
7	Spool Assembly	1529995	1530008	37	Handle Screw	1529964	1529964
8	Washer (T=0.5)	1178949	1178949	38	Washer	1092781	1092781
9	Click Gear	1126316	1126316	39	Body	1530002	1530014
10	Main Shaft	1279725	1529194	40	Slider Retainer	1126332	1126332
11	Nut Set Screw	1126258	1126258	41	Screw	1188428	1188428
12	Rotor Nut	1085606	1085606	42	Slider	1279738	1529195
13	Bail Arm Screw	1448222	1448222	43	Slider Screw	1126275	1126275
14	Bail Holder	1529996	1530009	44	Rear Cover	1530003	1530015
15	Bushing	1188261	1188261	45	Oscillation Gear	1252730	1347984
16	Screw	1536760	1536760	46	Bushing	1108938	1108938
17	Bail Arm	1529997	1529997	47	Screw	1497921	1085900
18	Brass Bushing	1536761	1536761	48	Reduction Gear	1252732	1252732
19	Line Roller	1529959	1529959	49	Drive Gear	1279734	1279734
20	Washer	1529960	1529960	50	Washer	1114764	1114764
21	Bail Assembly	1529998	1530010	51	Body Cover	1530004	1530016
22	Screw	1411137	1411137	52	Screw	1447884	1447884
23	Bail Arm Cover	1529999	1530011	53	Screw	1529196	1529196
24	Trip Spring	1119106	1119106	54	Handle Rivet Assembly	1530005	1530005
25	Trip Linkage	1252713	1252713	55	Bushing	1529970	1529970
26	Bail Slider	1126272	1126272	56	Handle Knob	1529971	1529971
27	Trip Bar	1530000	1530012	57	Screw	1119121	1119121
28	Rotor	1530001	1530013	58	Handle Knob Cover	1529972	1529972
29	Screw	1126451	1092844	59	Handle Assembly	1530006	1530006
30	Pinion Cover	1252715	1252715				