




# ORRA S 20 30



Abu-sp-Orra S-20 30-00



# PARTS LIST OF ORRA S 20 30

ITEM#	DESCRIPTION	ORRA S 20	ORRA S 30	ITEM#	DESCRIPTION	ORRA S 20	ORRA S 30
1	Drag knob Assembly	1252750	1252750	34	Rotor	1252760	1252769
	Spool Assembly	1252766	1252771	35	Trip Bar	1252712	1252712
	Spare Spool Assembly	1252767	1252772	36	Trip Linkage	1252713	1252713
2	Spool	1253725	1253727	37	Trip Bushing	1126272	1126272
2	Spare Spool	1253726	1253728	38	Trip Spring	1119106	1119106
3	Keyed washer	1126304	1252691	39	Bail Arm Cover	1252714	1252714
4	Spool Washer	1126307	1126366	40	Screw	1126326	1126326
5	Felt Washer	1252751	1252752	41	Pinion Cover	1252715	1252715
6	Carbon Washer	1126305	1126368	42	Clutch Spring	1252716	1252716
7	Clicker holder	1252692	1252692	43	Bearing 7X13X4	1252717	1252717
8	Spool Clicker	1252693	1252693	44	Bearing Holder	1252718	1252718
9	Spool Bottom	1252695	1252694	45	Clutch Assembly	1252719	1252719
10	Retaining Clip	1252697	1252696	46	Pinion	1252720	1252720
11	Spool shim thick T=0,5	1178953	1178953	47	Screw	1252723	1252723
11	Spool shim thin T=0,3	1178954	1178954	48	Clutch Switch Spring	1252761	1252761
12	Mainshaft Sleeve	1252698	1252698	49	Screw	1085342	1085342
13	Bushing	1252753	1252753	50	Clutch Switch	1252762	1252762
14	Mainshaft washer	1252700	1252700	51	Drive Gear	1252725	1252725
15	Mainshaft	1252701	1252701	52	Shim	1085287	1085287
16	Rotor Set Screw	1126258	1126258	53	C-Clip	1252726	1252726
17	Rotor Set Plate	1252702	1252702	54	Body Trim	1252727	1252727
18	Rotor Nut	1085273	1085273	55	Handle Assembly	1252763	1252763
19	Balance Weight	1252703	1252703	56	Screw	1252729	1252729
20	Line Roller Screw	1126261	1126261	57	Bushing	1108938	1108938
21	Bail Arm	1252754	1252754	58	Oscillation Gear	1252730	1252730
22	Brass bushing	1252755	1252755	59	Washer	1252731	1252731
23	POM bushing	1252756	1252756	60	Reduction Gear	1252732	1252732
24	Line Roller	1252705	1252705	61	Oscillation Guide	1252733	1252733
25	Bearing 5X8X2,5	1112125	1112125	62	Oscillation Slider	1252734	1252734
26	Bail Assembly	1252757	1252758	63	Screw	1126275	1126275
27	Bail Arm Screw	1126379	1126379	64	Oscillation Cover	1252768	1252768
28	Bushing	1188261	1188261	65	Body Cover	1252764	1252770
29	E-clip	1252707	1252707	66	Gearbox	1252765	1252765
30	O-ring	1252708	1252708	67	Dust Cap	1252738	1252738
31	Bail Holder	1252759	1252759	68	Line clip	1252739	1252739
32	Screw	1125962	1125962	69	Line clip spring	1252740	1252740
33	Bail Holder Cover	1252710	1252710	70	Rotor Washer	1114764	1114764