



ABU SP SILVER MAX20/30/40 00

Abu Garcia PARTS LIST OF SILVER MAX20/30/40

| ITEM# | DESCRIPTION | SILVER MAX20 | SILVER MAX30 | SILVER MAX40 | ITEM# | DESCRIPTION | SILVER MAX20 | SILVER MAX30 | SILVER MAX40 |
|-------|--------------------|--------------|--------------|--------------|-------|----------------------|--------------|--------------|--------------|
| 1 | Drag Knob Assembly | 1411162 | 1411162 | 1411162 | 30 | Screw | 1092844 | 1092844 | 1092844 |
| 2 | Retainer Ring | 1085295 | 1085295 | 1085295 | 31 | Bearing Retainer | 1252715 | 1252715 | 1252715 |
| 3 | Key Washer | 1085296 | 1085296 | 1085296 | 32 | Washer | 1114764 | 1114764 | 1114764 |
| 4 | Eared Washer | 1085297 | 1085297 | 1085297 | 33 | Bearing 7*13*4 | 1252717 | 1252717 | 1252717 |
| 5 | Washer | 1085298 | 1085298 | 1085298 | 34 | Bearing Holder | 1252718 | 1252718 | 1252718 |
| 6 | Spool | 1411163 | 1411170 | 1411174 | 35 | Clutch Spring | 1252716 | 1252716 | 1252716 |
| 7 | Washer (T=0.5) | 1178949 | 1178949 | 1178949 | 36 | Clutch Assembly | 1252719 | 1252719 | 1252719 |
| 8 | Click Gear | 1126316 | 1126316 | 1126316 | 37 | Pinion | 1279732 | 1279732 | 1279732 |
| 9 | Main Shaft | 1279725 | 1279725 | 1279748 | 38 | Screw | 1141435 | 1141435 | 1141435 |
| 10 | Bail Arm Screw | 1126379 | 1126379 | 1126379 | 39 | Bushing | 1279733 | 1279733 | 1279733 |
| 11 | Bail Holder | 1252709 | 1252709 | 1252709 | 40 | Clutch Switch Spring | 1252722 | 1252722 | 1252722 |
| 12 | O-Ring | 1252708 | 1252708 | 1252708 | 41 | IAR Switch | 1252721 | 1252721 | 1252721 |
| 13 | E-Clip | 1252707 | 1252707 | 1252707 | 42 | Drive Gear | 1279734 | 1279734 | 1279734 |
| 14 | Bushing | 1188261 | 1188261 | 1188261 | 43 | Body Cover | 1411166 | 1411166 | 1411177 |
| 15 | Rotor | 1411164 | 1411171 | 1411175 | 44 | Reduction Gear | 1252732 | 1252732 | 1252732 |
| 16 | Rotor Nut | 1085606 | 1085606 | 1085606 | 45 | Body | 1411167 | 1411172 | 1411178 |
| 17 | Nut Set Screw | 1126258 | 1126258 | 1126258 | 46 | Washer | 1092781 | 1092781 | 1092781 |
| 18 | Bail Arm Screw | 1411134 | 1411134 | 1411134 | 47 | Handle Cap | 1279767 | 1279767 | 1279767 |
| 19 | Bail Arm | 1252704 | 1252704 | 1252704 | 48 | Slider Retainer | 1126332 | 1126332 | 1121651 |
| 20 | Bail Bearing | 1112125 | 1112125 | 1112125 | 49 | Screw | 1188428 | 1188428 | 1188428 |
| 21 | Line Roller | 1252705 | 1252705 | 1252705 | 50 | Slider Screw | 1126275 | 1126275 | 1126275 |
| 22 | Washer | 1110165 | 1110165 | 1110165 | 51 | Slider | 1279738 | 1279738 | 1279756 |
| 23 | Bail Assembly | 1411136 | 1411149 | 1411155 | 52 | Rear Cover | 1279768 | 1279768 | 1279779 |
| 24 | Screw | 1411137 | 1411137 | 1411137 | 53 | Oscillation Gear | 1252730 | 1252730 | 1253720 |
| 25 | Rotor Cover | 1411165 | 1411165 | 1411176 | 54 | Bushing | 1108938 | 1108938 | 1108938 |
| 26 | Trip Spring | 1119106 | 1119106 | 1119106 | 55 | Screw | 1085599 | 1085599 | 1119026 |
| 27 | Trip Bushing | 1126272 | 1126272 | 1126272 | 56 | Screw | 1117984 | 1117984 | 1117984 |
| 28 | Trip Linkage | 1252713 | 1252713 | 1252713 | 57 | Handle Assembly | 1411168 | 1411168 | 1411168 |
| 29 | Bail Trip Lever | 1411139 | 1411150 | 1411157 | 58 | Spool Assembly | 1411169 | 1411173 | 1411179 |