

MODEL: ABU SP EMAXSP40

ITEM	DESCRIPTION	SAP#	ITEM	DESCRIPTION	SAP#
1	DRAG KNOB ASSY	1488052	40	BUSHING	1404814
2	STOP RING	1488053	41	WASHER	1205893
3	KEY WASHER (2REQ)	1446956	42	SCREW (3REQ)	1210692
4	EARED WASHER	1446957	43	BEARING COVER	1495540
5	DRAG WASHER	1225637	44	BEARING (4REQ)	1378807
6	SPOOL	1488054	45	BEARING SLEEVE	1488070
6A	SPOOL ASSY	1488055	46	ONE WAY CLUTCH	1380128
7	LINE CLIP SPRING	1216569	47	CLUTCH SPRING	1378810
8	LINE CLIP	1488056	48	PINION GEAR ASSY	1488071
9	SPOOL CLICK	1446960	49	BUSHING	1488072
10	SPOOL SPRING	1214415	50	SCREW	1200816
11	SCREW	1216396	51	N-R CAM	1488073
12	SHEET WASHER	1201745	52	SCREW	1200745
13	CLICK GEAR	1446961	53	SCREW	1488074
14	SPOOL SHAFT WASHER	1378777	54	SWITCH SPRING	1378885
15	MAIN SHAFT	1488057	55	IAR SWITCH	1488075
16	SCREW	1378779	56	DUST CAP	1488076
17	BAIL HOLDER	1488058	57	SCREW (6REQ)	1378818
18	BAIL WIRE ASSY	1488059	58	BEARING RETAINER (2REQ)	1488077
19	LOWER BUSHING	1380122	59	SIDE COVER	1488078
20	UPPER BUSHING	1380123	60	DRIVE GEAR	1380133
21	LINE ROLLER	1488060	61	SHIM	1488079
22	BEARING	1200781	62	HANDLE ASSY	1488080
23	LINE ROLLER COLLAR	1488061	63	O/S SLIDER	1409802
24	SCREW	1488062	64	SCREW	1395731
25	BAIL ARM	1488063	65	O/S GEAR PIN	1378827
26	SCREW	1378789	66	O/S GEAR BEARING	1216643
27	SCREW	1488064	67	O/S GEAR	1403870
28	BAIL ARM COVER	1488065	68	O/S GEAR BUSHING	1378829
29	BAIL ARM SPRING	1378849	69	SCREW	1395732
30	SPRING SEAT	1378793	70	UPPER O/S SLIDER GUIDE	1488081
31	PIVOT LEVER	1378794	71	LOWER O/S SLIDER GUIDE	1488082
32	TRIP PLUNGER	1488066	72	TRANSFER GEAR	1403857
33	ROTOR BRAKE	1378851	73	REAR COVER	1488083
34	RUBBER SLEEVE	1378853	74	BODY ASSY	1488084
35	ROTOR BRAKE SPRING	1378852	75	HANDLE SUB-ASSY	1488085
36	ROTOR	1488067	76	BUSHING (2REQ)	1438531
37	ROTOR NUT	1488068	77	T KNOB	1446970
38	ROTOR NUT WASHER	1378802	78	SCREW	1241728
39	SCREW	1378803	79	HANDLE KNOB COVER	1446971

EXPLODED VIEW

