



PARTS LIST OF MAXZSP5

ITEM#	DESCRIPTION	PART#(05)	ITEM#	DESCRIPTION	PART#(05)
1	Drag Knob Assembly	1529593	29	Screw	1197283
2	Retainer Ring	1092606	30	Bearing Retainer	1280406
3	Spool Washer	1280353	31	Washer	1114764
4	Key Washer	1280355	32	Bearing 7*14*4	1085280
5	Washer	1536759	33	Bearing Holder	1115558
6	Spool	1536588	34	Clutch Assembly	1102144
7	Spool Assembly	1537729	35	Pinion	1536771
8	Washer (T=0.5)	1178949	36	Clutch Spring	1252716
9	Click Gear	1085271	37	Handle Screw	1537733
10	Main Shaft	1280357	38	Body	1537734
11	Nut Set Screw	1529596	39	Slider Retainer	1121651
12	Rotor Nut	1085606	40	Screw	1385624
13	Bail Arm Screw	1448222	41	Slider	1188579
14	Bail Holder	1537730	42	Screw	1126275
15	Bushing	1538277	43	Rear Cover	1530099
16	Screw	1536760	44	Bearing 5*8*2.5	1112125
17	Bail Arm	1537731	45	Oscillation Gear	1280412
18	Bearing 4*7*2.5	1275826	46	Reduction Gear	1256967
19	Line Roller	1529959	47	Bearing 7*11*3	1085280
20	Washer	1529960	48	Drive Gear	1538809
21	Bail Assembly	1529961	49	Washer	1085287
22	Screw	1411137	50	Body Cover	1537735
23	Bail Arm Cover	1529962	51	Screw	1529968
24	Trip Spring	1126273	52	Handle Rivet Assembly	1530043
25	Trip Linkage	1252713	53	Handle Knob	1537736
26	Bail Slider	1128143	54	Screw	1119121
27	Trip Bar	1280403	55	Handle Knob Cover	1529972
28	Rotor	1537732	56	Handle Assembly	1537737