


Abu Garcia PRO MAX 20
30
40



ABU SP PRO MAX20/30/40 00

Abu Garcia PARTS LIST OF PRO MAX20/30/40

ITEM#	DESCRIPTION	PRO MAX20	PRO MAX30	PRO MAX40	ITEM#	DESCRIPTION	PRO MAX20	PRO MAX30	PRO MAX40
1	Drag Knob Assembly	1411180	1411180	1411180	30	Screw	1092844	1092844	1092844
2	Retainer Ring	1085295	1085295	1085295	31	Bearing Retainer	1252715	1252715	1252715
3	Key Washer	1085296	1085296	1085296	32	Washer	1114764	1114764	1114764
4	Eared Washer	1085297	1085297	1085297	33	Bearing 7*13*4	1252717	1252717	1252717
5	Washer	1085298	1085298	1085298	34	Bearing Holder	1252718	1252718	1252718
6	Spool	1411181	1411193	1411197	35	Clutch Spring	1252716	1252716	1252716
7	Washer (T=0.5)	1178949	1178949	1178949	36	Clutch Assembly	1252719	1252719	1252719
8	Click Gear	1126316	1126316	1126316	37	Pinion	1279732	1279732	1279732
9	Main Shaft	1279725	1279725	1279748	38	Screw	1141435	1141435	1141435
10	Bail Arm Screw	1126379	1126379	1126379	39	Bushing	1279733	1279733	1279733
11	Bail Holder	1411182	1411182	1411182	40	Clutch Switch Spring	1252722	1252722	1252722
12	O-Ring	1252708	1252708	1252708	41	IAR Switch	1411186	1411186	1411186
13	E-Clip	1252707	1252707	1252707	42	Drive Gear	1279734	1279734	1279734
14	Bushing	1188261	1188261	1188261	43	Body Cover	1411187	1411187	1411200
15	Rotor	1411183	1411194	1411198	44	Reduction Gear	1252732	1252732	1252732
16	Rotor Nut	1085606	1085606	1085606	45	Body	1411188	1411195	1411201
17	Nut Set Screw	1126258	1126258	1126258	46	Washer	1092781	1092781	1092781
18	Bail Arm Screw	1411134	1411134	1411134	47	Handle Cap	1411189	1411189	1411189
19	Bail Arm	1411184	1411184	1411184	48	Slider Retainer	1126332	1126332	1121651
20	Ball Bearing	1112125	1112125	1112125	49	Screw	1188428	1188428	1188428
21	Line Roller	1252705	1252705	1252705	50	Slider Screw	1126275	1126275	1126275
22	Washer	1110165	1110165	1110165	51	Slider	1279738	1279738	1279756
23	Bail Assembly	1411136	1411149	1411155	52	Rear Cover	1411190	1411190	1411202
24	Screw	1411137	1411137	1411137	53	Oscillation Gear	1252730	1252730	1253720
25	Rotor Cover	1411185	1411185	1411199	54	Ball Bearing	1112125	1112125	1112125
26	Trip Spring	1119106	1119106	1119106	55	Screw	1085599	1085599	1119026
27	Trip Bushing	1126272	1126272	1126272	56	Screw	1117984	1117984	1117984
28	Trip Linkage	1252713	1252713	1252713	57	Handle Assembly	1411191	1411191	1411191
29	Bail Trip Lever	1411139	1411150	1411157	58	Spool Assembly	1411192	1411196	1411203