



Ambassadeur Silver Max 17 00

1129927

34-12546-0

PARTS LIST OF AMBASSADEUR SILVER MAX

ITEM#	DESCRIPTION	SILVER MAX	ITEM#	DESCRIPTION	SILVER MAX	ITEM#	DESCRIPTION	SILVER MAX
1	LEFT SIDE PLATE	1134484	27	FRONT COVER	1134488	53	RETAINER	1134468
2	MAG DIAL	1134430	28	SCREW	1134453	54	MAIN GEAR SHAFT PLATE	1134469
3	CLICK SPRING	1134431	29	LINE GUIDE SHAFT	1134454	55	SCREW	1104820
4	O-RING	1134432	31	FRAME	1134489	56	MAIN GEAR SHAFT	1134470
5	CAM CURVE A	1134433	32	THUMBAR	1134490	57	LEVEL WIND GEAR	1065960
6	CAM CURVE B	1134434	33	YOKE	1138560	58	RATCHET	1134471
7	LINE REJECTER	1134435	34	YOKE SPRING	1104810	59	DRAG WASHER	1065962
8	SCREW	1134436	35	PINION	1134457	60	MAIN GEAR	1134472
9	COIL SPRING	1134437	36	BUSHING	1134458	61	DRAG WASHER	1134473
10	SCREW	1134438	37	CLUTCH SPRING	1134459	62	PRESSURE WASHER	1134474
11	MAGNET HOLDER	1134439	38	SCREW	1134460	63	IAR BEARING	1134475
12	WASHER	1134440	39	SPRING	1104807	64	IAR SLEEVE	1134476
13	BALL BEARING	1134485	40	KICK LEVER	1134461	65	BALL BEARING	1134477
14	LOCK RING	1134442	41	CLUTCH CAM	1134462	66	WASHER	1134478
15	SPOOL	1134443	42	RIGHT SIDE PLATE	1134491	67	CLICK SPRING	1104824
16	RETAINER	1104799	43	SCREW	1134492	68	SPRING WASHER	1065971
17	BUSHING	1134444	44	O-RING	1134465	69	WASHER	1134497
18	LINE GUIDE	1134486	45	THUMB SCREW	1134493	70	STAR WHEEL	1134498
19	PAWL	1134446	46	O-RING	1104812	71	SPRING WASHER	1065974
20	WASHER	1134447	47	BALL BEARING	1134494	72	HANDLE	1134499
21	LINE GUIDE NUT	1134487	48	WASHER	1095593	73	HANDLE NUT	1138561
22	WORM SHAFT TUBE	1095574	49	COLLAR	1104813	74	HANDLE NUT COVER	1134500
23	WORM SHAFT	1134449	50	WASHER	1104814	75	SCREW	1134501
24	WASHER	1134450	51	BRAKE KNOB	1104815			
25	GEAR	1134451	52	BALL BEARING	1134467			