



Please specify reel model number and number in reel foot when ordering parts.

Ambassadeur Silver Max LH 18 00

Vid beställning av reservdelar bör alltid rulltyp och nummerbeteckning under rullfoten anges

1137029

34-12574-1

ITEM#	PART #	DESCRIPTION	ITEM#	PART #	DESCRIPTION
1	1138836	RIGHT SIDE PLATE	39	1138854	SPRING
2	1134430	MAG DIAL	40	1138855	KICK LEVER
3	1134431	CLICK SPRING	41	1138856	CLUTCH CAM
4	1134432	O-RING	42	1138858	LEFT SIDE PLATE
5	1134433	CAM CURVE A	43	1134492	SCREW
6	1134434	CAM CURVE B	44	1134465	O-RING
7	1138838	LINE REJECTER	45	1134493	THUMB SCREW
8	1134436	SCREW	46	1104812	O-RING
9	1134437	COIL SPRING	47	1134494	BALL BEARING
10	1134438	SCREW	48	1095593	WASHER
11	1134439	MAGNET HOLDER	49	1104813	COLLAR
12	1134440	WASHER	50	1104814	WASHER
13	1134485	BALL BEARING	51	1104815	BRAKE KNOB
14	1134442	LOCK RING	52	1134467	BALL BEARING
15	1134443	SPOOL	53	1134468	RETAINER
16	1104799	RETAINER	54	1134469	MAIN GEAR SHAFT PLATE
17	1134444	BUSHING	55	1104820	SCREW
18	1134486	LINE GUIDE	56	1138860	MAIN GEAR SHAFT
19	1134446	PAWL	57	1065960	LEVEL WIND GEAR
20	1134447	WASHER	58	1134471	RATCHET
21	1134487	LINE GUIDE NUT	59	1065962	DRAG WASHER
22	1095574	WORM SHAFT TUBE	60	1138861	MAIN GEAR
23	1138839	WORM SHAFT	61	1134473	DRAG WASHER
24	1134450	WASHER	62	1134474	PRESSURE WASHER
25	1134451	GEAR	63	1134475	IAR BEARING
27	1138841	FRONT COVER	64	1134476	IAR SLEEVE
28	1134453	SCREW	65	1134477	BALL BEARING
29	1134454	LINE GUIDE SHAFT	66	1134478	WASHER
31	1138844	FRAME	67	1104824	CLICK SPRING
32	1138847	THUMBAR	68	1065971	SPRING WASHER
33	1138849	YOKE	69	1134497	WASHER
34	1104810	YOKE SPRING	70	1138863	STAR WHEEL
35	1138852	PINION	71	1065974	SPRING WASHER
36	1134458	BUSHING	72	1141285	HANDLE
37	1138853	CLUTCH SPRING	73	1138865	HANDLE NUT
38	1134460	SCREW	74	1134500	HANDLE NUT COVER
			75	1134501	SCREW