



Please specify reel model number and number in reelfoot when ordering parts.

Vid beställning av reservdelar bör alltid rulltyp och nummer beteckning under rullfoten anges.

Ambassadeur SX6600 23 00
1292730 34-12984-0

ITEM#	PART#	DESCRIPTION	ITEM#	PART#	DESCRIPTION
1	1307908	FRAME COMPLETE	36	1160962	CLUTCH PLATE COMP.
2	1307916	THUMB REST	37	1121563	PIN OF KICK LEVER
3	1160960	LEFT INNER SIDE PLATE	38	1121565	KICK LEVER
4	1121550	MIDDLE GEAR	39	1121569	LIFT CURVE
5	1133385	E RING	40	1121566	SCREW
6	1307920	LEFT SIDE COVER SUB ASSEMBLY	41	1121568	TWISTING SPRING
7	1116093	PLASTIC WASHER	42	1121564	TWISTING SPRING
8	1122204	SCREW	43	1121567	YOKE
9	1121606	WORM SHAFT	44	1121571	YOKE SPRING
10	1307926	LINE GUIDE	45	1121570	PINION
11	1121607	LINE GUIDE SHAFT	46	1307942	RIGHT SIDE COVER SUB ASSEMBLY
12	1122207	LEVEL WIND GUARD	47	1122205	SCREW
13	1206527	PAWL	48	1133387	O RING
14	1307928	PAWL SUPPORT	49	1121573	BASE WASHER
15	1121556	BEARING OF WORM SHAFT	50	1307948	MECHANICAL BRAKE KNOB
16	1124736	COG GEAR	51	1121589	SPRING WASHER
17	1124735	BALL BEARING	52	1307949	STAR WHEEL COMPLETE
18	1121968	BRAKE WEIGHT (6X)	53	1121577	SPRING WASHER
19	1124734	BRAKE WEIGHT HOLDER	54	1307953	HANDLE ARM COMPLETE
20	1307930	SPOOL	55	1307955	HANDLE ARM RIVETED
21	1307933	SPOOL PIN	56	1307957	HANDLE KNOB
22	1307935	SPOOL COMPLETE	57	1307958	HANDLE BUSHING
23	1121599	C RING	58	1307959	HANDLE SCREW
24	1122206	BALL BEARING	59	1307960	HANDLE KNOB CAP
25	1133388	SCREW	60	1133390	HANDLE NUT
26	1307938	MAIN GEAR SHAFT	61	1160954	NUT COVER
27	1121597	RATCHET WHEEL	62	1133391	SCREW
28	1121596	METAL WASHER	63	1206553	WASHER
29	1128099	DRAG WASHER	64	1121604	CLICKER COMPLETE
30	1121593	MAIN GEAR	65	1124738	SLIDE BLOCK
31	1121595	DRAG WASHER	66	1124740	CLICK GEAR
32	1121592	METAL WASHER	67	1124769	CLICK SPRING
33	1121591	EARED WASHER	68	1124770	ALARM BRACKET
34	1121590	METAL WASHER	69	1121602	TWISTING SPRING
35	1133389	IAR SLEEVE	70	1161136	LINE ALARM BUTTON