



Key	Part Description for Model 475B/00	Part No
1	Handle Screw	R4E15
2	Handle Assembly	R4F16
3	Handle Only	R4D8
4	Spindle Spring	R6C4
5	Spindle Cap	R6E5
6	Ball Bearing – Sealed S/S	R4J1
7	Spacer Bush	R4L1
8	Ball Bearing Retainer	R4K5
9	Spindle	R6A16
10	Brake Lever & Pad	R5C3
11	Brake Button	R7K5
12	Brake Lever Spring	R5H2
13	Metal Spindle Washer	R2L2
14	Spindle Hex Nut	R6F2
15	Spool with Handles	R4B-475B
16	Back Plate Assembly without Spool	R1A-475B

**Please Note:** If your reel is pre year 2000 you will need to disregard R4F16 (Key No. 2) and replace it with R4F13