



Key	Part Description for Model 475TCS	Part No
1	Handle Screw	R4E15
2	Handle Only	R4D8
3	Handle assembly	R4F16
4	Spindle Screw	R6E1
5	Spindle Nut	R6B12
6	Spindle Spring	R6C6
7	D Washer	R6D1
8	Brass Bush	R4J9
9	Retaining Bush	R4K5
10	Brake Lever & Pad	R5C3
11	Brake Button	R7K5
12	Brake Lever Spring	R5H2
13	Micarta Spindle Washer	R6J9
14	Fibre Spindle Washer	R6J1
15	Spindle	R6A1NZ
16	Spindle Hex Nut	R6F1
17	Spool with Handles	R4B-475TCS
18	Back Plate Assembly without Spool	R1A-475TCS