

Key	Part	Description	Key	Part	Description
1	R6B9	Spindle Tension Knob	9	R6A28	Spindle
2	R6L4	Washer Set	10	R6J6	Fibre Washer
3	R7F7	Handle Assembly	11	R1A	Reel without Spool
4	R7F6	Handle Assembly	12	R5E10	Ratchet Button
5	R4M3B	Handle Plate & Screw	13	R2DEF4	Bolt, Nut, Washer (turbo)
6	R4M3A	Handle Plate Spacer	14	R2A8	Base Assembly
7	R4B	Spool only	15	R2G13	Base Lock Spring
8	R5B4	Ratchet Wheel	16	R6F3	Dome Hex Nut



65GRT



CONGRATULATIONS and thank you for purchasing one of our Australian made turbocast reels as your choice of fishing reel. These reels are constructed from the highest quality materials to ensure your reel will last for many years.

Plus, all these other advantages -

Long, accurate casts:

Now, with only the minimum of practice you will be able to cast further and more accurately than ever before.

Control large fish with ease:

Powerful one-to-one direct wind means you only need about a quarter of the effort required to lift a similar weight on a spinning reel.

You can fish harder and longer:

Simple, rugged construction means you can forget that fiddly maintenance, because your Alvey reel will resist the effects of saltwater and sand.

Special Features

- Rapid Retrieve Handle Plate
- Turbo Cast
- Strong Graphite Back Plate
- Tri Tension Knob
- Fibreglass Spool with Stainless Steel Bush

More comfortable fishing: Low winch-mount rods let you fish with your arms in a relaxed position.

No line twist: Use a small free-running swivel as the last piece in any rig and you'll minimise any line twist. (See illustrations inside)



Alvey 10 Year Guarantee: Any faulty Alvey part or reel will be replaced at no charge providing the manufacturer finds the part or reel has had normal usage and attention.

Reel Icon Pty Ltd Trading as
Alvey Reels Australia ABN 57 625 261 707
2-6 Antimony Street Carole Park Qld 4300
t: +61 7 3271 2844 f: +61 7 3271 2451

For more hints and tips on maintenance,
please visit the **spare parts** page at
www.alvey.com.au
e: info@alvey.com.au
#alveyreels

Recommended Line Size

Your 65GRT reel will hold approximately 650 metres of 9 kg line. If fishing near rocks or other hazards use heavier line to help avoid line breakage.

Filling the Spool with Line


Always take the line from the front of the dispenser, never the side.

Wind firmly and evenly onto the spool, spreading the line with your fingers to give a smooth casting base.

Never stretch a nylon monofilament onto a spool; when it goes back to its original length it will exert strong enough crushing action to damage your spool.

Never allow loose coils to develop on your spool through careless uneven winding.

Adopt the habit of applying light finger tension when retrieving line and spread evenly over its bed.



Selecting a Rod

Your rod and reel outfit should be balanced so you can hold it comfortably over long periods. A matched set, which has a point of balance where it's held in the left hand, will give you the most comfortable posture. The ideal rod for this reel should be 3.6 to 4.1m in length.


The use of a short butt brings the reel into a natural position for rewinding with your elbows at your side and without strain.

Turbo Cast System

This new ultra smooth pivot system has a tough and durable design with an easy to use thumb press, it will not corrode, has a casting locator and will improve your casting distance, just follow the instructions below.


The Simple method for LONG DISTANCE SURF CASTING With the world's best side-cast reel – ALVEY!

1. To begin, place fingers of left hand on spool lip and thumb on release lever. Press lever... turn spool




2. Turn spool a full quarter to open-face casting position.


3. Release line from open runner. Restrain line with thumb on spool.



4. Casting position: Arms high rod held over shoulders, reel above rod.



5. Casting action: Punch hard with right hand, pull downward with left hand.




6. Casting drive: Follow through while releasing line grip as power is applied. Rod butt must clear left leg.




7. End of cast: Trap line at reel base. Turn drum back to fishing position.



8. Return line to open runner.



9 & 10 A comfortable fishing position makes hooking, playing or landing a fish more efficient.



If you're left-handed simply carry out above instructions the other way round.


Rigs & Swivels

When used properly a brass swivel is a very inexpensive and efficient way to keep a fishing line in good condition. Curls and twists in a line can be caused by many things, but can be kept to a minimum by the correct use of a swivel

Swivel Sizes

Line breaking strain	Swivel size
1 – 5 kg	No 14
5 – 8 kg	No 12
8 – 15 kg	No 10
15 – 20 kg	No 9

Swivel must be above sinker



65GRT



Direct Wind Models

The direct wind series of reels are the ultimate in simplicity. These reels allow the angler to fish with the minimum of fuss and attention to their gear. The light weight allows the serious fisherman to fish extensive hours without tiring. The thrill of controlling a fish without the interference of a non reverse drag action puts the sport back in sports fishing. The direct wind reel allows the spool to be completely free running, allowing even the most timid biting fish to take line without interference.

Rapid Retrieve Handle-plate

The outer handle provides maximum winding power at 1:1 ratio to turn and control large fish. The inner handle is designed to give up to a 35% increase in your retrieve rate, for running a lure or recovering your rig quickly if you lose the bait.

Playing the fish

Once the fish has been hooked always keep a bend in the rod by holding it at an angle to the fish. With the power of an Alvey reel you are in control. Do not rush the fish. Allow the drag to tire the fish. Many times the fish is lost in the shore break. Keep a steady tension on your line, a bend in the rod and ease the fish ashore.

Fish Alert

When leaving the rod and reel unattended, activate the fish alert on the back of the reel by selecting the 'ON' position. If a fish takes line, a warning noise will be heard. Turn off the alert by selecting the 'OFF' position.

Maintenance

Use light machine oil on working spindles, handle and index mechanism. After each day of fishing wash off salt and sand and lubricate as above before storage.