



NO. PART NAME

- 1 DRAG KNOB PLATE
- 2 DRAG KNOB
- 3 DRAG CLICKER WASHER
- 4 DRAG NUT
- 5 DRAG SPRING
- 6 DRAG CLICK
- 7 CLICKER FIXED PLATE
- 8 DRAG KNOB PLATE SCREW
- 9 SPOOL RING
- 10 WASHER
- 11 DRAG WASHER
- 12 WASHER
- 13 ALUMINUM SPOOL
- 14 LINE FITTING PART
- 15 CLICK WASHER
- 16 CLICK GEAR
- 17 CLICKER
- 18 CLICKER SCREW
- 19 SPOOL SCREW
- 20 ROTOR COVER SCREW
- 21 ROTOR NUT WASHER
- 22 ROTOR
- 23 BAIL ARM
- 24 BAIL HOLDER SCREW
- 25 ROTOR SIDE PLATE
- 26 SIDE PLATE SCREW
- 27 LINE ROLLER CAP
- 28 BAIL WIRE
- 29 LINE ROLLER WASHER
- 30 LINE ROLLER
- 31 LINE ROLLER BALL BEARING
- 32 LINE ROLLER CAP
- 33 BAIL WIRE
- 34 BAIL ARM SHAFT
- 35 COMPRESSION SPRING
- 36 ROTOR SPRING

NO. PART NAME

- 37 ROTOR SIDE PLATE
- 38 MAIN SHAFT
- 39 DRIVE GEAR FITTING WASHER
- 40 MAIN SHAFT BALL BEARING X2
- 41 MAIN SHAFT BALL BEARING SLEEVE
- 42 ONE WAY CLUTCH INNER RING
- 43 ONE WAY CLUTCH BALL BEARING
- 44 ONE WAY CLUTCH SPRING
- 45 DRIVE GEAR
- 46 DRIVE GEAR FITTING WASHER SCREW
- 47 ANTI REVERSE WASHER
- 48 ANTI REVERSE SHAFT
- 49 ANTI REVERSE LEVER
- 50 ANTI REVERSE SCREW
- 51 ALUMINUM DIE-CASTING HANDLE
- 52 HEXAGON WASHER
- 53 HANDLE SCREW
- 54 MAIN BODY
- 55 SLIDER COVER PLATE
- 56 SLIDER COVER PLATE SCREW
- 57 SLIDER SHAFT
- 58 OSCILLATION GEAR
- 59 OSCILLATION GEAR SCREW
- 60 SLIDER
- 61 SLIDER SCREW
- 62 MAIN BODY DECORATION
- 63 BODY COVER BALL BEARING
- 64 GEAR
- 65 GEAR WASHER
- 66 MAIN BODY COVER BALL BEARING
- 67 MAIN BODY COVER
- 68 MAIN BODY COVER SCREW
- 69 MAIN BODY COVER SCREW
- 70 MAIN BODY DECORATION
- 71 ROTOR SCREW