



1 - Main Housing	MXJ5.8-001	15 - Spool Spring Washer (2 req.)	MXJ5.8-015	29 - Drive Shaft Bearing (2 req.)	MXJ5.8-029	44 - Lever Arm	MXJ5.8-044	58 - Handel Knob	MXJ5.8-058	73 - Clicker Spring	MXJ5.8-073
2 - Gear cover	MXJ5.8-002	16- Spool Spring	MXJ5.8-016	30 - End Housing	MXJ5.8-030	45 - Teflon Washer (2 req.)	MXJ5.8-045	59 - Knob bearing	MXJ5.8-059	74 - Clicker arm	MXJ5.8-074
3 - Cover Screw (2 req.)	MXJ5.8-003	17 - Brake Bearing	MXJ5.8-017	31 - Dog	MXJ5.8-031	46 - Drive Washer	MXJ5.8-046	60 -Knob Washer	MXJ5.8-060	75 - Clicker E-clip	MXJ5.8-075
4 - Spool Shaft	MXJ5.8-004	18- Brake Disk	MXJ5.8-018	32 - Dog Cover Screw (2 req.)	MXJ5.8-032	47- Preset Washer	MXJ5.8-047	61 - Spring Washer	MXJ5.8-061	76 - MC ASSY :	MXJ5.8-076
4A-Shaft Shoulder	MXJ5.8-004A	19 - N/A	MXJ5.8-019	33 - Dog Cover	MXJ5.8-033	48- Preset Spring	MXJ5.8-048	62 - Lock Washer	MXJ5.8-062	A- MC Knob	
4B-Shaft Pin	MXJ5.8-004B	20- Antireverse Gear	MXJ5.8-020	34 - Stop Pin (2 req.)	MXJ5.8-034	49 - Preset Knob	MXJ5.8-049	63 - Nut	MXJ5.8-063	B- MC Screw	
5 - Belleville Washers (4 req.)	MXJ5.8-005	21 - Disk Ring	MXJ5.8-021	35 - Pin Screw (2 req.)	MXJ5.8-035	49A - Preset Knob Detent	MXJ5.8-049A	64 -Knob Cap	MXJ5.8-064	C- MC Spring	
6 - Pusher Bushing	MXJ5.8-006	22 - Pinion Gear	MXJ5.8-022	36 - Handle Knob	MXJ5.8-036	50 - Crank Arm	MXJ5.8-050	65 - Knob Cap Screws (2 req.)	MXJ5.8-065	D- MC Ball	
7 - Spool Bearing	MXJ5.8-007	23 - Pinion Bearing	MXJ5.8-023	37 - Knob Screw	MXJ5.8-037	51 - Crank Arm Washer	MXJ5.8-051	66 - Reel Foot	MXJ5.8-066	E- MC Washer	
8 - Spool Tube	MXJ5.8-008	24 - Drive Shaft	MXJ5.8-024	38 - End Housing Screw (3 req.)	MXJ5.8-038	52 - Acorn Nut	MXJ5.8-052	67 - Reel Foot screws	MXJ5.8-067	F- MC Housing	
9 - Clicker Gear Retainer Ring	MXJ5.8-009	25 - Connection Arm	MXJ5.8-025	39 - Drive Shaft Tube	MXJ5.8-039	53 - Locking Plate	MXJ5.8-053	68 - Clamp	MXJ5.8-068	G- MC Stator	
10 - Clicker Gear	MXJ5.8-010	26 - Friction Ring	MXJ5.8-026	40 - Drive Shaft Washer	MXJ5.8-040	54 - Screws (2 req.)	MXJ5.8-054	69 - Clamp Screws	MXJ5.8-069	H- MC Shaft	
11 - Spool	MXJ5.8-011	27 - Friction Washer	MXJ5.8-027	41 - Male Cam	MXJ5.8-041	55 - Handel Shaft Washer	MXJ5.8-055	70 - Clicker Pin	MXJ5.8-070		
12- Brake Pad	MXJ5.8-012	28 - Drive Shaft Gear	MXJ5.8-028	42 - Male Cam Pin (3 req.)	MXJ5.8-042	56 - Handel Knob Shaft	MXJ5.8-056	71 - Clicker Housing	MXJ5.8-071		
14- Spool Bearing	MXJ5.8-014	28A - Drive Shaft Washer	MXJ5.8-028A	43 - Female Cam	MXJ5.8-043	57 - Handel Shaft Bearing	MXJ5.8-057	72 - Clicker Washer	MXJ5.8-072		