



For MXJ 6/4-MC Model ONLY

A- MC knob  
B- MC Screw  
C- MC Spring  
D- MC Ball  
E- MC Washer  
F- MC housing  
G- MC stator  
H- MC shaft

1 - Main Housing	MXJ6/4-001	16 - Spool Spring	MXJ6/4-016	32 - Washer RT	MAJ6/4-032	47 - Pin Screw	MXJ6/4-47	61 - Crank Arm	MXJ6/4-061	76 - Knob Washer (optional)	MXJ6/4-076
2 - Gear Cover	MXJ6/4-002	17 - Brake Bearing	MXJ6/4-017	33 - Fork	MAJ6/4-033	48 - End Housing Screw	MXJ6/4-48	62 - Crank Arm Washer	MXJ6/4-062	77 - Spring Washer	MXJ6/4-077
3 - Cover Screw	MXJ6/4-003	18 - Brake Disk	MXJ6/4-018	34 - Fork Spring	MAJ6/4-034	49 - Drive Shaft Tub	MXJ6/4-49	63 - Pusher Knob E-Clip	MXJ6/4-063	78 - Lock Washer	MXJ6/4-078
4 - Spool Haft	MXJ6/4-004	19 - Antireverse Gear	MXJ6/4-019	35 - Pusher	MAJ6/4-035	50 - Drive Shaft Washer	MXJ6/4-50	64 - Crank Arm Nut	MXJ6/4-064	79 - Nut	MXJ6/4-079
4A- Shaft Shoulder	MXJ6/4-004A	20 - Disk Ring	MXJ6/4-020	36 - Pushar Spring	MAJ6/4-036	51 - Male Cam	MXJ6/4-51	65 - Push knob	MXJ6/4-065	80 - Knob Cap	MXJ6/4-080
4B- Shaft Pin	MXJ6/4-004B	22 - Large Pinion Gear	MXJ6/4-022	37 - Drive Shaft	MAJ6/4-037	51A- Male Cam Pin (3 req.)	MXJ6/4-51A	66 - Luck Plate	MXJ6/4-066	81 - Knob Cap Screws (2 req.)	MXJ6/4-081
5 - Belleville Washer (4 req.)	MXJ6/4-005	23 - Small Pinion Gear	MXJ6/4-023	38 - Pusher Washer	MAJ6/4-038	52 - Lever Arm	MXJ6/4-52	67 - Release Arm Spring	MXJ6/4-067	82 - Clicker Pin	MXJ6/4-082
6 - Pusher Bushing	MXJ6/4-006	24 - Pinion Bearing	MXJ6/4-024	39 - Pusher E-Clip	MAJ6/4-039	53 - Female Cam	MXJ6/4-53	68 - Spring Pin	MXJ6/4-068	83 - Pin Support	MXJ6/4-083
7 - Spool Bearing	MXJ6/4-007	25 - Drive Shaft Stop Nut	MXJ6/4-025	40 - Drive Shaft Bearing (2 req.)	MAJ6/4-040	54 - Handel Knob	MXJ6/4-54	69 - Release Arm	MXJ6/4-069	84 - Pin Washer	MXJ6/4-084
8 - Spool Tube	MXJ6/4-008	25A - Stop Nut Pin	MXJ6/4-025A	41 - End Housing	MAJ6/4-041	55 - Knob Screw	MXJ6/4-55	70 - Push Knob Cover	MXJ6/4-070	85 - Clicker Spring (2 req.)	MXJ6/4-085
9 - Clicker Gear Retainer Ring	MXJ6/4-009	26 - Connection Arm	MXJ6/4-026	41A - N/A	N/A	56 - Teflon Washer (2 req.)	MXJ6/4-56	71 - Cover Screws (2 req.)	MXJ6/4-071	86 - Clicker Arm	MXJ6/4-086
10 - Clicker Gear	MXJ6/4-010	27 - Friction Ring	MXJ6/4-027	42 - Dog Washer	MAJ6/4-042	57 - Drive Washer	MXJ6/4-57	72A - Handel Shaft Washer	MXJ6/4-072A	87 - Pin-E-Clip	MXJ6/4-087
11 - Spool	MXJ6/4-011	28 - Washer LF	MXJ6/4-028	43 - Dog	MAJ6/4-043	58 - Preset Washer	MXJ6/4-58	72 - Handel Knob Shaft	MXJ6/4-072	88 - Reel Foot	MXJ6/4-088
12 - Brake pad	MXJ6/4-012	29 - Drive Shaft Small Gear	MXJ6/4-029	44 - Dog Cover Screw (2 req.)	MAJ6/4-044	59 - Preset Spring	MXJ6/4-59	73 - Handel Shaft Bearing	MXJ6/4-073	89 - Reel Foot Screws	MXJ6/4-089
14 - Spool Bearing	MXJ6/4-014	30 - Washer MDL	MXJ6/4-030	45 - Dog Cover	MAJ6/4-045	60 - Preset Knob	MXJ6/4-60	74 - Handel Knob	MXJ6/4-074	90 - Reel Foot Clamp	MXJ6/4-090
15 - Spool Spring Washer (2 req.)	MXJ6/4-015	31 - Drive Shaft Large Gear	MXJ6/4-031	46 - Stop Pin (2 req.)	MAJ6/4-046	60A- Preset Knob Detent (2 req.)	MXJ6/4-60A	75 - Handel Tub	MXJ6/4-075	91 - Clamp Screws (2 req.)	MXJ6/4-091
										92- MC ASSY	MXJ6/4-092