



- 01. ENDCAP HOUSING SCREW (PACK OF 12)
- 02. ENDCAP HOUSING
- 03. DOG SPRING SET
- 04. DOG SET
- 05. HURNESS LUG SCREW (PACK OF 2)
- 06. HARNESS LUG
- 07. FRAME
- 09. OUTER BRAKE SCREW
- 10. OUTER BRAKE SCREWS SPRING WASHER
- 11. OUTER BRAKE BEARING
- 12. OUTER BRAKE
- 14. E-CLIP WASHER (PACK OF 3)
- 15. BRAKE DISC
- 16. BRAKE RETAINER SPRING
- 17. INNER BRAKE
- 18. BRAKE PIN (PACK OF 2)
- 19. BRAKE DISC SPRING (PACK OF 3)
- 20. INNER BRAKE SPOOL BEARING
- 21. SPOOL
- 22. CLICKER DISC
- 23. CLICKER DISC SCREW (PACK OF 4)
- 24. SPOOL TUBE
- 25. SPOOL BEARING
- 26. SPACER
- 27. SPOOL SHAFT
- 28. BELLEVILLE WASHER (PACK OF 2)
- 29. PRESET KNOB SCREW (PACK OF 3)
- 30. PRESET KNOB
- 31. LEVER SPACER
- 32. LEVER
- 33. PRESET KNOB SPACER
- 34. CAM HOUSING OUTER WASHER
- 35. GLIDE PLATE SCREW (PACK OF 3)
- 36. GLIDE PLATE
- 37. GLIDE PLATE SPACER (PACK OF 3)
- 38. ENDCAP SCREW (PACK OF 11)
- 39. PUSH KNOB COVER SCREW (PACK OF 2)
- 40. PUSH KNOB COVER
- 41. RELEASE ARM
- 42. RELEASE ARM SPRING
- 43. PUSH KNOB NUT LOCK PLATE
- 44. PUSH KNOB
- 45. RELEASE ARM PIN
- 46. PUSH KNOB WASHER
- 47. HANDLE KNOB
- 47-a. HANDLE KNOB INSIDE SET
- 48. HANDLE ARM
- 49. HANDLE ARM THRUST WASHER
- 50. DRIVE SHAFT BEARING
- 51. DRIVE SHAFT TUBE
- 52. CLICKER KNOB
- 53. CLICKER SHAFT PIN
- 54. CLICKER SHAFT SPRING
- 55. CLICKER SHAFT
- 56. CLICKER SPACER TUBE
- 57. CLICKER KNOB WASHER
- 58. CLICKER SHAFT PIN
- 59. FREE LIMIT PIN SET
- 60. FULL LIMIT PIN SET
- 62. ENDCAP
- 65. CAM HOUSING
- 66. CAM HOUSING INNER WASHER
- 67. FEMALE CAM
- 68. MALE CAM
- 69. PRESET NUT
- 70. PINION BEARING / PRESET NUT BEARING
- 71. SPRING WASHER (PACK OF 2)
- 72. CAM HOUSING SCREW (PACK OF 2)
- 73. CLICKER POSITION BALL SPRING
- 74. CLICKER POSITION BALL
- 75. CLICKER WASHER
- 76. CLICKER RETAINING RING
- 77. CLICKER HOUSING
- 78. SPRING WASHER (PACK OF 2)
- 79. CLICKER HOUSING SCREW (PACK OF 2)
- 80. DRIVE SHAFT BEARING
- 81. DRIVE SHAFT
- 82. DRIVE SHAFT LARGE GEAR
- 83. DRIVE SHAFT LARGE GEAR SPACER
- 84. DRIVE SHAFT SMALL GEAR
- 85. DRIVE SHAFT SMALL GEAR SPACER
- 86. DRIVE SHAFT STOP NUT
- 87. REEL FOOT
- 88. SPRING WASHER (PACK OF 4)
- 89. REEL FOOT SCREW (PACK OF 4)
- 90. CLAMP SET
- 90-a. CLAMP
- 90-b. CLAMP SCREW (PACK OF 2)
- 90-c. CLAMP NUT (PACK OF 2)