



		Part Numbers				Part Numbers	
Item#	Part description	702	700U	Item#	Part description	702	700U
1	BEARING COVER SCREW		62972	37	LINE ROLLER SCREW	1083517	1091997
2	CLICKER SPRING		63044	38	ROTOR COVER SCREW		1083518
3	CLICKER PAWL		63045	39	SPOOL CAP SCREW		1083519
4	BAIL ARM	1107424	1107425	40	MAINSHAFT	108352C	1083983
5	DRAG WASHER	1083453	1083965	41	OSCILLATION GEAR	1083521	1083984
6	BAIL SPRING	1083454	1083966	42	OSCILLATION GEAR BUSHING	1083522	1091998
7	BODY COVER	1107426	1107427	43	SET SCREW		1083523
8	OSC. GEAR BEARING	1083456	1092069	44	BAIL ARM SCREW		1083524
9	DRIVE GEAR BEARING	1083457	1083968	45	PINION	1083525	1083985
10	BEARING CLIP	1083458	1083969	46	PINION SLEEVE		1083526
11	BEARING COVER	1083489	1083970	47	LINE ROLLER	1083527	1083986
12	PINION BEARING		1083490	48	ROTOR BODY	1107464	1107465
13	BEARING WASHER		1083491	49	ROTOR NUT		1083529
14	COUNTER BALANCE, MIDDLE	1083492	1083971	50	ROTOR SET PLATE		1083530
15	COUNTER BALANCE	1083493	1083972	51	ROTOR WASHER		1083531
16	FRICTION WASHER	1083494	1083973	52	ROTOR COVER B/A	1083532	1083988
17	DRAG KNOB	1107428	1107459	53	ROTOR COVER B/H	1083533	1083989
18	DRAG ADJUSTMENT CLICKER	1083497	1083975	54	SPOOL CAP	1083534	1083990
19	DRAG SPRING	1083498	1092070	55	OSCILLATION SLIDER	1083535	1083991
20	DRAG SPRING WASHER		1083499	56	SPOOL BUSHING	1083536	1083992
21	DRAG ADJUSTER	1083500	1083976	57	SPOOL	1083537	1083993
22	DRAG PLATE	1096037	1083977	58	SPOOL NUT		1083538
23	DRIVE GEAR WASHER		1083502	59	ROLLER BUSHING	1083540	1083995
24	DRIVE GEAR	1083503	1083978	60	BAIL TRIP BAR	1083541	1083996
25	GEARBOX	1107460	1107461	61	BAIL SPRING PIVOT	1083542	1083997
26	HANDLE ASSEMBLY		1107462	62	OSC. SLIDER SCREW		1083543
27	HANDLE SCREW WASHER		1083506	63	IAR KNOB SCREW		1083544
28	HANDLE SCREW		1107463	64	OSC. BUSHING SCREW	1083545	1092071
29	IAR KNOB		1083508	65	COUNTERBALANCE SCREW	1083546	1092072
30	IAR LEVER	1083509	1083980	66	SPOOL BUSHING WASHER		1083992
31	IAR LEVER SPRING	1083510	1083981	67	ROTOR SHIM*		1083983
32	IAR OUTER RING		1083511	68	E-CLIP		1083982
33	IAR PAWL	1083512	N/A	69	SPOOL NUT WASHER		1083994
34	PIN LEVER		1083513	70	IAR PIN HOLDER & PINS		1083547
35	IAR SPRING		1083514	71	BAIL ASSEMBLY	1107466	1107467
36	BODY COVER SCREW		1083515		SPARE SPOOL	1099160	1099181

*702 - 2 pcs; 700U - 1 pc.