



ABU GARCIA CARDINAL 672

Abu Garcia Cardinal 672 Parts List

ITEM#	Part description	Part Numbers	ITEM#	Part description	Part Numbers
1	BEARING COVER SCREW	1095872	37	LINE ROLLER SCREW	1095883
2	CLICKER SPRING	63044	38	ROTOR COVER SCREW	1095884
3	CLICKER PAWL	63045	39	SPOOL CAP SCREW	1095885
4	BAIL ARM	1095873	40	MAINSHAFT	1095886
5	DRAG WASHER	1083453	41	OSCILLATION GEAR	1098359
6	BAIL SPRING	1083454	42	OSCILLATION GEAR BUSHING	1083522
7	BODY COVER	1095874	43	SET SCREW	1095887
8	OSC. GEAR BEARING	1095877	44	BAIL ARM SCREW	1095888
9	DRIVE GEAR BEARING	1095875	45	PINION	1083525
10	BEARING CLIP	1083458	46	PINION SLEEVE	1083526
11	BEARING COVER	1083489	47	LINE ROLLER	1095889
12	PINION BEARING	1095878	48	ROTOR BODY	1095890
13	BEARING WASHER	1083491	49	ROTOR NUT	1083529
14	COUNTER BALANCE, MIDDLE	1083492	50	ROTOR SET PLATE	1083530
15	COUNTER BALANCE	1083493	51	ROTOR WASHER	1083531
16	FRICTION WASHER	1083494	52	ROTOR COVER B/A	1083532
17	DRAG KNOB	1095876	53	ROTOR COVER B/H	1083533
18	DRAG ADJUSTMENT CLICKER	1083497	54	SPOOL CAP	1083534
19	DRAG SPRING	1083498	55	OSCILLATION SLIDER	1098360
20	DRAG SPRING WASHER	1083499	56	SPOOL BUSHING	1095973
21	DRAG ADJUSTER	1083500	57	SPOOL	1095974
22	DRAG PLATE	1095972	58	SPOOL NUT	1095891
23	DRIVE GEAR WASHER	1083502	59	ROLLER BUSHING	1083540
24	DRIVE GEAR	1098358	60	BAIL TRIP BAR	1083541
25	GEARBOX	1095879	61	BAIL SPRING PIVOT	1083542
26	HANDLE ASSEMBLY	1095880	62	OSC. SLIDER SCREW	1095892
27	HANDLE SCREW WASHER	1083508	63	IAR KNOB SCREW	1095893
28	HANDLE SCREW	1095881	64	OSC. BUSHING SCREW	1095894
29	IAR KNOB	1083508	65	COUNTERBALANCE SCREW	1095895
30	IAR LEVER	1083509	66	SPOOL BUSHING BEARING	1095896
31	IAR LEVER SPRING	1083510	67	ROTOR SHIM	1083963
32	IAR OUTER RING	1083511	68	DRAG WASHER B	1095897
33	IAR PAWL	1083512	69	SPOOL SEAL	1095898
34	PIN LEVER	1083513	70	IAR PIN HOLDER & PINS	1083547
35	IAR SPRING	1083514	71	BAIL ASSEMBLY	1095896
36	BODY COVER SCREW	1095882	72	SCREW SEAL	1096036
			37	SPARE SPOOL	1089159