




SPREADER POLE BRACKET

PART NUMBER: 112846

INSTRUCTIONS: 106467



MODEL 12846

WARRANTY INFORMATION

Notice!!! Please contact customer service directly at the E-mail or phone number listed below for any quality issues

***** Warranty cannot be honored without an original, dated receipt *****

IMPORTANT - PLEASE READ:

This product is warranted to the original retail purchaser (from an authorized dealer) and is non-transferable. Clam Outdoors Inc. has a ONE (1) year **manufacturer's defect warranty** from the date of original purchase. Defective parts will be replaced or repaired (at the manufacturer's option) if found to be defective within ONE (1) year from the date of original purchase. Warranty will be void if product has been subject to neglect, misuse, improper installation, misapplication, alteration, accident including but not limited to improper maintenance, or use of unauthorized parts or attachments. Please read the entire owner's manual to ensure proper installation, use and storage

To submit a warranty claim request, please use one of the following methods:

- Customer Service Hrs: 9am to 4pm, Monday – Friday Central Standard Time
- Clam Corporation
Attn: Customer Service – Warranty Department
12135 Brockton Lane
Rogers, MN 55369
- Phone: 763-231-4120
- Fax: 763-231-4121
- Email: customerservice@clamcorp.com
- Website: Clamoutdoors.com

In your request, please include your full name, address, phone number, a copy of your receipt, a brief description of the problem, and pictures to clearly show the area(s) of concern. Our Warranty Department will review your request, and a Clam representative will contact you regarding your claim status. All returns must be shipped to us postage pre-prepaid.

LIMITATION OF LIABILITY


It is expressly understood that Clam Outdoors Inc. liability for its products, whether due to breach of warranty, negligence, strict liability, or otherwise, is limited to the repair of the product as stated above. Clam Outdoors Inc. is not liable for any injury, loss, damage, or expense, whether direct or consequential, including but not limited to loss of use, income, profit, or damage to material arising in connection with the sale, installation, use of, inability to use, or the repair or replacement of Clam Outdoors Inc. products. Clam Outdoors Inc. reserves the right to make alterations or modifications in its products at any time, which in its opinion, may improve the performance and efficiency of the product. Clam Outdoors Inc. shall not be obligated to make such alterations or modifications to products already in service.

Due to Clam's continued product improvements, Clam reserves the right to change specifications without notice. For complete details see the assembly and or operating instructions that are provided and packed with the purchased product.


PARTS LIST

QTY.	PART NO.	DESCRIPTION
2	105854	WLDMT, POLE BRACKET
1	105855	ASSY, STRAP, POLE BRACKET
5	101088	SCREW, 1/4-20 X 0.75 PTH GR5 YZ
10	101081	WASHER, 1/4 FLAT REG YZ
5	101082	NUT, 1/4-20 THIN NYLOCK YZ
1	106467	INSTRUCTIONS, SPREADER POLE BRACKET

1. POSITION EACH BRACKET IN A LOCATION THAT IS BEST FOR YOUR APPLICATION.
2. MARK THE POSITION OF THE HOLES YOUR USING AND DRILL WITH 1/4" THRU BASE.
3. SECURELY TIGHTEN IN PLACE WITH FASTENERS AS SHOWN.



1. PLACE POLES INSIDE THE BOTH BRACKETS.
2. DETERMINE BEST POSITION TO PLACE TIGHTENING STRAP AND DRILL 1/4" HOLE THRU BASE.
3. SECURELY TIGHTEN IN PLACE WITH FASTENERS AS SHOWN



BASE SHOWN FOR ILLUSTRATION ONLY AND MAY NOT MATCH YOUR CURRENT BASE.