



"EASI-LITE" MODELS 431, 432A, 433A

Code No.	Description	Model 431	Model 432A	Model 433A
1	Filler Cap	425A1401	425A1401	425A1401
2	Tank with Check Valve	431-1631	432-1631	432-1631
3	Check Valve and Air Stem	621-5361	621-5361	621-5361
4	Pump Leather & Washer <i>216A5091</i>	216-5091	216-5091	216-5091
5	Pump Plunger Complete	242D5205	242D5205	242D5205
6	Generator Complete	412B2621 <i>H/2-562C</i>	414L2621	414L2621 <i>Disco 2000</i>
7	Valve & Generator Assembly	431C6605	432C6605	432C6605
8	Burner Ass'y Complete	421E3755	444B3755	446A3755
9	Stove Lid with Baffles	431-4851	432-4851	433-4851
10	Grate	431-4345	444-5535	—
11	Grate L.H.	—	—	446-5565
12	Grate R.H.	—	—	446-5535
13	Stove Box	431-4701	444-5521	—
14	Baffle	431-2195	—	—
15	Valve & Fuel Tube	431-6565 <i>412-6565*</i>	432-6565	432-6565

when you screw the valve, threads v. fine you must use Pipe Thread Dope

NOT teflon tape and when you attach old generator, must have pipe thread dope

never lock-tite