



MODEL 432

Code No.	Description	Model 432 (2-Burner)
1	Filler Cap Complete	425A1401
2	Pump Leather & Washer	216-5091
3	Pump Plunger Complete	242D5205
4	Air Stem & Check Valve	621-5361
5	Grate	444-5535
6	Burner Assembly Complete	444B3755
—	Tank with Check Valve Only	432-1591
7	Tank Complete	432-1651
8	Generator Complete	414K2621
9	Valve & Generator Assembly	432A6605