


MODEL 200, 200A, 236, 237



MODEL 220B, 220E

Code No.	Description	200, 200A Gasoline	220E, 220B Gasoline	236 Gasoline	237 Kerosene
1	Generator	T66	T44	236-299	237-299
2	Globe	550	330	660	660
3	Gasket, Filler Cap (I)	118B1361	118B1361	118B1361	118B1361
	(II)	425A1361	425A1361	425A1361	425A1361
	Core & Gasket Assembly (For 220B140)	118B1361	118B1361	118B1361	118B1361
4	Fount Complete	200C1654	220F1654	236C1654	236C1654
5	Burner Tube	200-3241	101-3241	236-3241	236-3241
6	Manifold Assembly	*200A3264	101-3264	Not requ'd	Not requ'd
7	Frame with Burner	200A3701	200A3701	236-3704	236-3704
8	Burner Assembly	—	—	—	—
9	Frame Assembly	200-6624	200-6624	—	—
10	Bail	242A4701	242A4701	236-4235	236-4235
11	Lock Nut	200-4701	200-4701	—	—
12	Ventilator	*200-4854	220F4854	236-4854	236-4854
13	Base Rest (Collar)	200E4895	200E4895	236A4895	237A4895
14	Valve Wheel & Screw	200C6491	200C6491	200C6491	200C6491
15	Valve Stem Complete	220C6534	220C6534	236-6534	236-6534
16	Ventilator Support	220B3405	220B3405	236-3405	236-3405
17	Ball Nut, Ventilator	203-4411	203-4411	203-4411	203-4411
18	Pump Leather	216-5091	216-5091	216-5091	216-5091
19	Filler Cap Complete	425A1401	425A1401	425A1401	425A1401
20	Tip Cleaner Assembly	—	220B3574	—	—
21	Fuel Tube & Needle	242A1481	220D1484	236-1484	Not requ'd
22	Eccentric Block	242-3045	118A3045	236-3045	237-3045
23	Burner Cap	242-3231	112-3231	236-3231	236-3231
24	Tip Cleaner	242-3531	220B3535	118B3535	118B3535
25	Frame	Not requ'd	Not requ'd	236-6035	236-6035
26	Frame	604A4565	104-1475	604A4565	604A4565
27	Pump Assembly	242D5201	242D5201	242D5201	242D5201
28	Air Stem	242B5321	242B5321	242B5321	242B5321
29	Check Valve	242B5381	242B5381	242B5381	242B5381
30	Valve Body Only	242-6075	220D607	236-6074	236-6545
31	Clip, Pump Cap	530A5071	530A5071	530A5071	530A5071
32	Universal Wrench (Accessory)	605A9505	605A9505	605A9505	605A9505
33	Screw for Valve Wheel	17-581	17-581	17-581	17-581
34	Pre-Heater Cup	Not requ'd	Not requ'd	Not requ'd	237-310
35	Alcohol Bottle	Not requ'd	Not requ'd	Not requ'd	249-9115
36	Air Tube	—	220B3225	—	—
37	Jamb Nut	605-2102	615-2101	605-2102	530-2101
38	Fuel Valve Complete	200-6571	220D6574	236-6574	237-6574
39	Pre-Heater Cup Clip	—	—	—	235-3115

Parts...No Longer Available