


**MODEL 325**



**MODEL 625**

Code No.	Description	Model 325
1	Generator	G4*
2	Globe	4
3	Mantle	999
4	Wrench (Accessory)	605A9505
5	Plunger Ass'y (Less Air Stem)	242D5201
6	Pump Leather & Washer	216-5091
7	Air Stem & Check Valve	621-5361
8	Ventilator	339-4855
9	Heat Shield	321-4605
10	Burner Frame	335-3265
11	Globe Base Rest	325-4895
12	Fount with Check Valve	325-1595
13	Filler Plug	425A1401
14	Bail	335-4235
15	Nut	604A4565
16	Stud	321-6035
17	Generator Jamb Nut	335-2105
18	Valve Ass'y (Less Generator)	321C6565
19	Valve & Generator Assembly	325-6575

\*Not Available in U.S.A.

Code No.	Description	Model 625 (Brown)
1	Generator	G5*
2	Globe	880
3	Mantle	1111
4	Wrench (Accessory)	605A9505
5	Plunger Ass'y (Less Air Stem)	242D5201
6	Pump Leather & Washer	216-5091
7	Air Stem & Check Valve	621-5361
8	Ventilator	621A4855
9	Heat Shield	621-4605
10	Burner Frame	621A3265
11	Globe Base Rest	625-4895
12	Fount with Check Valve	625-1595
13	Filler Plug	425A1401
14	Bail	621-4235
15	Nut	604A4565
16	Stud	321-6035
17	Generator Jamb Nut	335-2105
18	Valve Ass'y (Less Generator)	621C6565
19	Valve & Generator Assembly	625-6575

\*Not Available in U.S.A.