



**MODEL 325A**

Code No.	Description	325A
1	Generator	G7
2	Globe	4
3	Mantle	999
4	Wrench (Accessory)	605A9505
5	Plunger Ass'y (Less Air Stem)	242D5201
6	Pump Leather & Washer	216-5091
7	Air Stem & Check Valve	621-5361
8	Ventilator	339-4855
9	Heat Shield	321-4605
10	Burner Frame	335-3265
11	Globe Base Rest	325A4895
12	Fount with Check Valve	325-1591
13	Filler Plug	425A1401
14	Bail	335-4235
15	Nut	604A4565
16	Stud	321-6035
17	Valve Ass'y (Less Generator)	325-6565
18	Valve & Generator Assembly	325A6575