


COLEMAN PORTABLE OVEN



Model 5010A700

Replaceable Repair Parts

Description	Part No.
Grate	5010A5075
Latch Assembly	5010A1124
Heat Indicator	5010A1171
Door Hinge Pin	5010A1211
Door Less Hinge Pin	5010B5061