



2 BURNER MODELS 421D, 421, 411A, 411, 4M, 6H, 444

Code No.	Description	421D	6J, 4M, 4K, 421, 421A	411, 411A	414	444, 444A, 444B
1	Filler Cap (I) (II)	220B1401 425A1401	220B1401 425A1401	220B1401 425A1401	220B1401 425A1401	220B1401 425A1401
2	Filler Cap Gasket (I) (II)	118B1361 425A1361	118B1361 425A1361	118B1361 425A1361	118B1361 425A1361	118B1361 425A1361
	Core & Gasket Assembly (For 220B140)	118B135	118B135	118B135	118B135	118B135
3	Pump Leather	216-5091	216-5091	216-F	216-5091	216-5091
4	Pump Plunger Complete	242D5201	242D5201	242	242D5201	242D5201
5	Air Stem	242B5321	242B5321		242B5321	242B5321
6	Check Valve	242B5381	242B5381		242B5381	242B5381
7	Burner Rings — 5 cm (2")	382-9371	382-9371	382-9371	382-9371	382-9371
8	Burner Rings — 6.875 cm (2-3/4")	382-9381	382-9381	382-9381	382-9381	382-9381
9	Grate	*421-4345	425A	425A4345	414-4344	444-5534
10	Lock Nut	412S114	412	412S114	412S114	412S114
11	Valve Body	412B2071		412B2071	412B2071	412B2071
12	Generator Tube	412-2125		412-2125	414-2125	414-2125
13	Generator Coil	412-2195	412	412-2195	414-2195	414-2195
14	Generator Tip	412-2181	412	412-2181	435-2181	435-2181
15	Valve Wheel & Screw	412-2501	412-2501	412-2501	412-2501	412-2501
16	Needle Generator	412-2514	412-2514	412-2514	414-2514	414-2514
17	Valve Stem	412-2531	412-2531	412-2531	412-2531	412-2531
18	Manifold Tube					
19	Master Burner Body					
20	Lighting Lever	412-3531	412-3531	412-3531	412-3531	412-3531
21	Eccentric Block & Needle	412-6401	412-6401	412-6401	412-6401	413-6401
22	Fuel & Air Tube	412-6461	412-6461	412-6461	412-6461	444-6461
23	Valve & Generator Assembly	412-6604	412-6604	412-6604	414-6604	444-6601
24	Master Burner Bowl	413C3025	413C3025	413C3025	413C3025	413C3025
25	Auxiliary Burner Bowl	413C3065	413C3065	413C3065	413C3065	413C3065
26	Tank Less Fittings	425C1594	425C1594	425C1594	414-1594	444-1594
27	Tank with Pump	425C1654	425C1654	425C1654	414-1654	444-1654
28	Burner Cap & Screw	417-9371	417-9371	417-9371	417-9371	417-9371
29	Burner Cap & Screw	417-9381	417-9381	417-9381	417-9381	417-9381
30	Screw for Valve Wheel	17-581	17-581	17-581	17-581	17-581
31	Pump Cap Clip	530A5071	530A5071	530A5071	530A5071	530A5071
32	Burner Body & Valve					
33	Restrictor Ring				426-3285	444B2365
34	Master Burner Bracket	421-409	421-409	421-409	421-409	444-3754
35	Burner Assembly Complete	421-3754	421-3754	421-3754	414A3754	444-3754
36	Generator Complete	412A2621	412A2621	412A2621	414K2621	414K2621

Parts... No Longer Available

*Included 421A123 Grate Clips.

Handwritten: 412B2621 → 412-502C