


6Y2854010



Please order by part number, not key number.

SPINCASTING REEL TD1Pi/2Pi



Key NO.	Parts No.	Parts Name
49	E25-6101	Oiled washer A
50	374-9102	Spool adjusting cap metal
51	E23-0501	Spacer B
52	B17-5502	Spacer C
53	171-5201	"O" ring B
54	B85-3401	Cast control cap
55	353-4402	Set plate screw
56	B91-1714	Right side plate screw A
57	B91-1710	Right side plate screw B
58	812-0201	Drive shaft washer A
59	B35-8601	Ball bearing A
60	F02-7401	Drive shaft
61	E19-9401	Drive shaft retainer
62	B39-6503	Drive shaft retainer screw
63	E32-7701	Anti-reverse ratchet
64	E42-5301	Drive shaft washer B
65	F26-4401	Drive gear
66	F02-7801	Drag washer
67	F06-2501	Key washer
68	150-8901	Drag spring washer
69	F02-8001	Gear shaft collar
70	B55-3801	Oiled washer B
71	E42-1401	Roller clutch
72	E42-5401	Spacing sleeve
73	F02-8201	Click leaf spring holder

Key NO.	Parts No.	Parts Name
74	F03-2401	Click leaf spring
75	F02-8301	Star drag
76	150-9001	Friction washer
77	F26-4501	Handle assembly
78	341-5802	Handle nut
79	F02-8801	Handle nut plate
80	351-1803	Handle nut plate screw
81	F05-5501	Ball bearing C
82	F06-1301	Worm shaft gear
83	E42-5901	Stabilizer bar D
84	E03-7703	Worm shaft washer

TD2PI SPECIAL PARTS

13	F05-0301	Spool assembly
16	F07-4801	Frame assembly
17	F02-7909	Parning plate
19	F02-7301	Stabilizer bar A
23	F02-7601	Stabilizer bar C
28	F02-7501	Level wind guard
29	E28-4601	Worm shaft
43	F09-6612	Right side plate
56	B91-1715	Right side plate screw A
57	891-1712	Right side plate screw B
83	E42-6001	Stabilizer bar D