




14 BALLISTIC EX 4000H

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
14 BALLISTIC EX 4000H		1	6J096701	DRAG KNOB
14 BALLISTIC EX 4000H		2	6F710001	DRAG WASHER RETAINER
14 BALLISTIC EX 4000H		3	6F895302	DRAG KNOB CLICK PLATE
14 BALLISTIC EX 4000H		4	6F627101	DRAG WASHER
14 BALLISTIC EX 4000H		5	6F627301	EARED WASHER
14 BALLISTIC EX 4000H		6	6H714001	KEY WASHER
14 BALLISTIC EX 4000H		7	-	-
14 BALLISTIC EX 4000H		8	6J096501	SPOOL ASSEMBLY(2-8)
14 BALLISTIC EX 4000H		9	6G525101	BEARING RETAINER (A)
14 BALLISTIC EX 4000H		10	6B861704	BALL BEARING (B)
14 BALLISTIC EX 4000H		11	6G903900	WASHER (A)
14 BALLISTIC EX 4000H		12	6G694001	CLICK LEAF SPRING HOLDER
14 BALLISTIC EX 4000H		13	6F709002	SPOOL CLICK LEAF SPRING
14 BALLISTIC EX 4000H		14	6H641501	SPOOL METAL
14 BALLISTIC EX 4000H		15	6G224101	PIN
14 BALLISTIC EX 4000H		16	6H995201	PACKING(A)
14 BALLISTIC EX 4000H		17	6H995101	ROTOR NUT
14 BALLISTIC EX 4000H		18	6H022701	SCREW (A)
14 BALLISTIC EX 4000H		19	6H994306	ROTOR
14 BALLISTIC EX 4000H		20	6H413601	BAIL TRIP LEVER SPRING
14 BALLISTIC EX 4000H		21	6H994401	BAIL TRIP LEVER
14 BALLISTIC EX 4000H		22	6H417701	SCREW (B)
14 BALLISTIC EX 4000H		23	6H640601	BAIL SPRING SHAFT
14 BALLISTIC EX 4000H		24	6H576101	BAIL SPRING PLATE
14 BALLISTIC EX 4000H		25	6H640701	BAIL SPRING
14 BALLISTIC EX 4000H		26	6J089401	BAIL SPRING HOLDER
14 BALLISTIC EX 4000H		27	6H994601	COVER (A)
14 BALLISTIC EX 4000H		28	6H822601	SCREW (C)
14 BALLISTIC EX 4000H		29	6H728909	BAIL ARM
14 BALLISTIC EX 4000H		30	6H962401	COLLAR (A)
14 BALLISTIC EX 4000H		31	6H822501	SCREW (D)
14 BALLISTIC EX 4000H		32	6G195602	SCREW (E)
14 BALLISTIC EX 4000H		33	6G195501	COLLAR (B)
14 BALLISTIC EX 4000H		35	6G220701	COLLAR (C)
14 BALLISTIC EX 4000H		37	6J089901	LINE ROLLER
14 BALLISTIC EX 4000H		38	6G874201	COLLAR (D)
14 BALLISTIC EX 4000H		40	6J094401	BAIL ASSEMBLY
14 BALLISTIC EX 4000H		41	6H822501	SCREW (F)
14 BALLISTIC EX 4000H		42	6H730701	MAGNET ASSEMBLY
14 BALLISTIC EX 4000H		43	6H596501	SCREW (G)
14 BALLISTIC EX 4000H		44	6H639901	"O"RING (A)
14 BALLISTIC EX 4000H		45	6H642511	COVER (B)
14 BALLISTIC EX 4000H		46	6H665001	CLUTCH CAM RETAINER
14 BALLISTIC EX 4000H		47	6F641401	CLUTCH CAM
14 BALLISTIC EX 4000H		48	6G314501	ROLLER CLUTCH
14 BALLISTIC EX 4000H		49	6H782301	SPACING SLEEVE
14 BALLISTIC EX 4000H		50	6H509101	BEARING RETAINER(B)
14 BALLISTIC EX 4000H		51	6H624901	SCREW (H)
14 BALLISTIC EX 4000H		52	-	-
14 BALLISTIC EX 4000H		53	6G522801	BALL BEARING (C)
14 BALLISTIC EX 4000H		54	63712800	WASHER (C)
14 BALLISTIC EX 4000H		55	6G572501	SPRING WASHER
14 BALLISTIC EX 4000H		56	6G467102	BALL BEARING (D)
14 BALLISTIC EX 4000H		57	6J011501	MAIN SHAFT
14 BALLISTIC EX 4000H		58	6H639301	STABILIZER BAR
14 BALLISTIC EX 4000H		59	6J095101	BODY
14 BALLISTIC EX 4000H		60	6H639001	ANTI-REVERSE CAM
14 BALLISTIC EX 4000H		61	6H595401	ANTI-REVERSE LEVER
14 BALLISTIC EX 4000H		62	6H697801	ANTI-REVERSE CAM SPRING
14 BALLISTIC EX 4000H		63	6H640102	REAR COVER

