




# 18 CALDIA LT 6000D

Feel Alive.

Please quote by part number, not key number when ordering.  
spares@daiwaaustralia.com.au PH: (02) 8644 8644



S39110E, S39211E  
S39210E, S39411E  
S39410E, S39511E  
S39510E, S39711E  
S39910E, S39811E

18 CALDIA LT 1000S-P ~ LT 6000D

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
18 CALDIA LT 6000D	S39910E	1	6J579901	DRAG KNOB
18 CALDIA LT 6000D	S39910E	2	61704101	DRAG RING
18 CALDIA LT 6000D	S39910E	3	6J577501	DRAG DISC WASHER
18 CALDIA LT 6000D	S39910E	4	6J679001	ATD DRAG WASHER ( 1 pack - 3pcs )
18 CALDIA LT 6000D	S39910E	5	6J577301	DRAG LIP WASHER
18 CALDIA LT 6000D	S39910E	6	6J577501	DRAG DISC WASHER
18 CALDIA LT 6000D	S39910E	7	6J568601	LINE STOPPER PLATE
18 CALDIA LT 6000D	S39910E	8	6J558001	LINE STOPPER
18 CALDIA LT 6000D	S39910E	9	6J314801	LINE STOPPER SPRING
18 CALDIA LT 6000D	S39910E	10	6J701001	SPOOL ASSY (2~10)
18 CALDIA LT 6000D	S39910E	11	6F050100	SPOOL WASHER (A)
18 CALDIA LT 6000D	S39910E	12	6F050002	SPOOL WASHER (B)
18 CALDIA LT 6000D	S39910E	13	6J525101	CLICK LEAF SPRING
18 CALDIA LT 6000D	S39910E	14	6J576501	CLICK HOLDER
18 CALDIA LT 6000D	S39910E	15	6F049901	CLICK HOLDER WASHER
18 CALDIA LT 6000D	S39910E	16	6H995201	ROTOR NUT PACKING
18 CALDIA LT 6000D	S39910E	17	6H995101	ROTOR NUT
18 CALDIA LT 6000D	S39910E	18	6H022701	ROTOR NUT SCREW
18 CALDIA LT 6000D	S39910E	19	6H994333	ROTOR
18 CALDIA LT 6000D	S39910E	20	6H413601	KICK LEVER SPRING
18 CALDIA LT 6000D	S39910E	21	6H994401	KICK LEVER ASSY
18 CALDIA LT 6000D	S39910E	22	6H417701	KICK LEVER SCREW
18 CALDIA LT 6000D	S39910E	23	6H640601	ARM LEVER SHAFT
18 CALDIA LT 6000D	S39910E	24	6H576101	ARM LEVER SHAFT PLATE
18 CALDIA LT 6000D	S39910E	25	6H640701	ARM LEVER SHAFT SPRING
18 CALDIA LT 6000D	S39910E	26	6J089401	ARM LEVER SHAFT HOLDER
18 CALDIA LT 6000D	S39910E	27	6H994601	ARM LEVER SP COVER
18 CALDIA LT 6000D	S39910E	28	6H431301	ARM LEVER SP COVER SCREW
18 CALDIA LT 6000D	S39910E	29	6H960102	ARM LEVER
18 CALDIA LT 6000D	S39910E	30	6H962401	ARM LEVER COLLAR
18 CALDIA LT 6000D	S39910E	31	6H431201	ARM LEVER SCREW
18 CALDIA LT 6000D	S39910E	32	6H697701	ROLLER SCREW
18 CALDIA LT 6000D	S39910E	33	6H961001	ROLLER COLLAR (A)
18 CALDIA LT 6000D	S39910E	34	6H038301	ROLLER BEARING PACKING
18 CALDIA LT 6000D	S39910E	35	6G686903	ROLLER BALL BEARING
18 CALDIA LT 6000D	S39910E	36	6H960901	ROLLER BEARING COLLAR
18 CALDIA LT 6000D	S39910E	37	6G686703	LINE ROLLER
18 CALDIA LT 6000D	S39910E	38	6H960801	ROLLER COLLAR (B)
18 CALDIA LT 6000D	S39910E	39	6H960701	ROLLER COLLAR (C)
18 CALDIA LT 6000D	S39910E	40	6H994701	BAIL ASSY
18 CALDIA LT 6000D	S39910E	41	6H431201	BAIL HOLDER SCREW
18 CALDIA LT 6000D	S39910E	42	6J429301	MAGSEALED PLATE SCREW
18 CALDIA LT 6000D	S39910E	43	6J428901	MAGSEALED PLATE
18 CALDIA LT 6000D	S39910E	44	6J212901	MAGSEALED PLATE ORING
18 CALDIA LT 6000D	S39910E	45	6J428801	MAGSEALED CAP
18 CALDIA LT 6000D	S39910E	46	6J431601	ONEWAY CLUTCH WASHER
18 CALDIA LT 6000D	S39910E	47	6J309101	ONEWAY CLUTCH
18 CALDIA LT 6000D	S39910E	48	6G997301	PINION BEARING PLATE SCREW
18 CALDIA LT 6000D	S39910E	49	6J690501	CLUTCH RING
18 CALDIA LT 6000D	S39910E	50	6J020801	PINION BEARING PLATE
18 CALDIA LT 6000D	S39910E	51	6G522802	PINION BALL BEARING (A)
18 CALDIA LT 6000D	S39910E	52	63712800	PINION BEARING WASHER
18 CALDIA LT 6000D	S39910E	53	6Z023909	PINION + DRIVE GEAR SET
18 CALDIA LT 6000D	S39910E	54	6G572501	PINION BEARING SPRING WASHER
18 CALDIA LT 6000D	S39910E	55	6G467102	PINION BALL BEARING (B)
18 CALDIA LT 6000D	S39910E	56	-	PINION COLLAR WASHER
18 CALDIA LT 6000D	S39910E	57	6J428101	PINION COLLAR
18 CALDIA LT 6000D	S39910E	58	6J647602	BODY ASSY
18 CALDIA LT 6000D	S39910E	59	6J576102	MAIN SHAFT
18 CALDIA LT 6000D	S39910E	60	6J084806	OSCILLATING POST
18 CALDIA LT 6000D	S39910E	61	6J020501	STOPPER CAM
18 CALDIA LT 6000D	S39910E	62	6H595401	STOPPER LEVER
18 CALDIA LT 6000D	S39910E	63	6H697801	STOPPER CAM LEAF SPRING
18 CALDIA LT 6000D	S39910E	64	6J429401	REAR CAP
18 CALDIA LT 6000D	S39910E	65	6J389001	REAR CAP SCREW
18 CALDIA LT 6000D	S39910E	66	6J496901	OSCILLATING GEAR WASHER
18 CALDIA LT 6000D	S39910E	67	6J575901	OSCILLATING GEAR
18 CALDIA LT 6000D	S39910E	68	6B853101	OSCILLATING GEAR ORING
18 CALDIA LT 6000D	S39910E	69	6G522100	OSCILLATING GEAR BALL BEARING WASHER
18 CALDIA LT 6000D	S39910E	70	6G467105	OSCILLATING GEAR BALL BEARING
18 CALDIA LT 6000D	S39910E	71	6H463401	OSCILLATING GEAR BALL BEARING SCREW
18 CALDIA LT 6000D	S39910E	72	6G645301	DRIVE GEAR ORING
18 CALDIA LT 6000D	S39910E	73	63737800	DRIVE WASHER
18 CALDIA LT 6000D	S39910E	74	6G523405	DRIVE GEAR BALL BEARING (A)
18 CALDIA LT 6000D	S39910E	75	6J648401	BODY COVER ASSY
18 CALDIA LT 6000D	S39910E	76	6J389801	BODY COVER SCREW
18 CALDIA LT 6000D	S39910E	77	6H730801	HANDLE CAP PACKING
18 CALDIA LT 6000D	S39910E	78	6J701301	HANDLE ASSY
18 CALDIA LT 6000D	S39910E	79	6B861704	DRIVE GEAR BALL BEARING (B)
18 CALDIA LT 6000D	S39910E	80	6G525101	DRIVE BEARING RING
18 CALDIA LT 6000D	S39910E	81	6G672401	HANDLE CAP ORING
18 CALDIA LT 6000D	S39910E	82	6J429901	HANDLE CAP