




18 CALDIA LT 2500D-XH

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



18 CALDIA LT 1000S-P ~ LT 6000D

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
18 CALDIA LT 2500D-XH	S39411E	1	6J697601	DRAG KNOB
18 CALDIA LT 2500D-XH	S39411E	2	6J547101	DRAG RING
18 CALDIA LT 2500D-XH	S39411E	3	6J547001	DRAG DISC WASHER
18 CALDIA LT 2500D-XH	S39411E	4	6J678801	ATD DRAG WASHER (1 pack - 3pcs)
18 CALDIA LT 2500D-XH	S39411E	5	6J546902	DRAG LIP WASHER
18 CALDIA LT 2500D-XH	S39411E	6	6J547001	DRAG DISC WASHER
18 CALDIA LT 2500D-XH	S39411E	7	6J558101	LINE STOPPER PLATE
18 CALDIA LT 2500D-XH	S39411E	8	6J558001	LINE STOPPER
18 CALDIA LT 2500D-XH	S39411E	9	6J314801	LINE STOPPER SPRING
18 CALDIA LT 2500D-XH	S39411E	10	6J702901	SPOOL ASSY (2~10)
18 CALDIA LT 2500D-XH	S39411E	11	6E398000	SPOOL WASHER (A)
18 CALDIA LT 2500D-XH	S39411E	12	6E467101	SPOOL WASHER (B)
18 CALDIA LT 2500D-XH	S39411E	13	6J525101	CLICK LEAF SPRING
18 CALDIA LT 2500D-XH	S39411E	14	6J546201	CLICK HOLDER
18 CALDIA LT 2500D-XH	S39411E	15	6J703101	CLICK HOLDER WASHER
18 CALDIA LT 2500D-XH	S39411E	16	6H986901	ROTOR NUT PACKING
18 CALDIA LT 2500D-XH	S39411E	17	6H961101	ROTOR NUT
18 CALDIA LT 2500D-XH	S39411E	18	6H022701	ROTOR NUT SCREW
18 CALDIA LT 2500D-XH	S39411E	19	6J545303	ROTOR
18 CALDIA LT 2500D-XH	S39411E	20	6H413601	KICK LEVER SPRING
18 CALDIA LT 2500D-XH	S39411E	21	6J545401	KICK LEVER ASSY
18 CALDIA LT 2500D-XH	S39411E	22	6H417701	KICK LEVER SCREW
18 CALDIA LT 2500D-XH	S39411E	23	6J545601	ARM LEVER SHAFT
18 CALDIA LT 2500D-XH	S39411E	24	6H576101	ARM LEVER SHAFT PLATE
18 CALDIA LT 2500D-XH	S39411E	25	6J642801	ARM LEVER SHAFT SPRING
18 CALDIA LT 2500D-XH	S39411E	26	6H414301	ARM LEVER SHAFT HOLDER
18 CALDIA LT 2500D-XH	S39411E	27	6J545701	ARM LEVER SP COVER
18 CALDIA LT 2500D-XH	S39411E	28	6H431301	ARM LEVER SP COVER SCREW
18 CALDIA LT 2500D-XH	S39411E	29	6H960102	ARM LEVER
18 CALDIA LT 2500D-XH	S39411E	30	6H962401	ARM LEVER COLLAR
18 CALDIA LT 2500D-XH	S39411E	31	6H431201	ARM LEVER SCREW
18 CALDIA LT 2500D-XH	S39411E	32	6H697701	ROLLER SCREW
18 CALDIA LT 2500D-XH	S39411E	33	6H961001	ROLLER COLLAR (A)
18 CALDIA LT 2500D-XH	S39411E	34	6H038301	ROLLER BEARING PACKING
18 CALDIA LT 2500D-XH	S39411E	35	6G686903	ROLLER BALL BEARING
18 CALDIA LT 2500D-XH	S39411E	36	6H960901	ROLLER BEARING COLLAR
18 CALDIA LT 2500D-XH	S39411E	37	6G686703	LINE ROLLER
18 CALDIA LT 2500D-XH	S39411E	38	6H960801	ROLLER COLLAR (B)
18 CALDIA LT 2500D-XH	S39411E	39	6H960701	ROLLER COLLAR (C)
18 CALDIA LT 2500D-XH	S39411E	40	6J642001	BAIL ASSY
18 CALDIA LT 2500D-XH	S39411E	41	6H431201	BAIL HOLDER SCREW
18 CALDIA LT 2500D-XH	S39411E	42	6J429301	MAGSEALED PLATE SCREW
18 CALDIA LT 2500D-XH	S39411E	43	6J675201	MAGSEALED PLATE
18 CALDIA LT 2500D-XH	S39411E	44	6J354801	MAGSEALED PLATE ORING
18 CALDIA LT 2500D-XH	S39411E	45	6J445901	MAGSEALED CAP
18 CALDIA LT 2500D-XH	S39411E	46	6J639900	ONEWAY CLUTCH WASHER
18 CALDIA LT 2500D-XH	S39411E	47	6J388401	ONEWAY CLUTCH
18 CALDIA LT 2500D-XH	S39411E	48	6G997301	PINION BEARING PLATE SCREW
18 CALDIA LT 2500D-XH	S39411E	49	6J001403	CLUTCH RING
18 CALDIA LT 2500D-XH	S39411E	50	6H442201	PINION BEARING PLATE
18 CALDIA LT 2500D-XH	S39411E	51	6G467302	PINION BALL BEARING (A)
18 CALDIA LT 2500D-XH	S39411E	52	63758500	PINION BEARING WASHER
18 CALDIA LT 2500D-XH	S39411E	53	62023856	PINION + DRIVE GEAR SET
18 CALDIA LT 2500D-XH	S39411E	54	6J683001	PINION BEARING SPRING WASHER
18 CALDIA LT 2500D-XH	S39411E	55	6H959601	PINION BALL BEARING (B)
18 CALDIA LT 2500D-XH	S39411E	56	6G466103	PINION COLLAR WASHER
18 CALDIA LT 2500D-XH	S39411E	57	6J387701	PINION COLLAR
18 CALDIA LT 2500D-XH	S39411E	58	6J697102	BODY ASSY
18 CALDIA LT 2500D-XH	S39411E	59	6J544802	MAIN SHAFT
18 CALDIA LT 2500D-XH	S39411E	60	6J084805	OSCILLATING POST
18 CALDIA LT 2500D-XH	S39411E	61	6H595501	STOPPER CAM
18 CALDIA LT 2500D-XH	S39411E	62	6H595401	STOPPER LEVER
18 CALDIA LT 2500D-XH	S39411E	63	6H697801	STOPPER CAM LEAF SPRING
18 CALDIA LT 2500D-XH	S39411E	64	6J388901	REAR CAP
18 CALDIA LT 2500D-XH	S39411E	65	6J389001	REAR CAP SCREW
18 CALDIA LT 2500D-XH	S39411E	66	6J644701	OSCILLATING GEAR WASHER
18 CALDIA LT 2500D-XH	S39411E	67	6J544601	OSCILLATING GEAR
18 CALDIA LT 2500D-XH	S39411E	68	6H770601	OSCILLATING GEAR ORING
18 CALDIA LT 2500D-XH	S39411E	69	6H129200	OSCILLATING GEAR BALL BEARING WASHER
18 CALDIA LT 2500D-XH	S39411E	70	6G469005	OSCILLATING GEAR BALL BEARING
18 CALDIA LT 2500D-XH	S39411E	71	6G997001	OSCILLATING GEAR BALL BEARING SCREW
18 CALDIA LT 2500D-XH	S39411E	72	6G670501	DRIVE GEAR ORING
18 CALDIA LT 2500D-XH	S39411E	73	63758500	DRIVE WASHER
18 CALDIA LT 2500D-XH	S39411E	74	6G467302	DRIVE GEAR BALL BEARING (A)
18 CALDIA LT 2500D-XH	S39411E	75	6J626901	BODY COVER ASSY
18 CALDIA LT 2500D-XH	S39411E	76	6J389801	BODY COVER SCREW
18 CALDIA LT 2500D-XH	S39411E	77	6J130201	HANDLE CAP PACKING
18 CALDIA LT 2500D-XH	S39411E	78	6J697901	HANDLE ASSY
18 CALDIA LT 2500D-XH	S39411E	79	6G522706	DRIVE GEAR BALL BEARING (B)
18 CALDIA LT 2500D-XH	S39411E	80	6G472401	DRIVE BEARING RING
18 CALDIA LT 2500D-XH	S39411E	81	6G162401	HANDLE CAP ORING
18 CALDIA LT 2500D-XH	S39411E	82	6J389701	HANDLE CAP