


SPINNING REEL **EMCAST SPORT 4500/5000**



Key		
No.	Parts No.	Parts Name
1	W52-3103	BODY
2	W36-0202	HANDLE SCREW
3	W36-0101	HANDLE WASHER
4	W52-5601	A/R LEVER
5	W36-0401	A/R LEVER SCREW
6	W36-0502	REAR COVER RET
7	W36-0601	REAR COVER A SCREW
8	W52-5701	REAR COVER A
9	W52-5801	REAR COVER B
10	W36-0901	REAR COVER B SCREW
11	W36-1002	WORM SHAFT RET
12,14	W36-1101	WORM SHAFT BUSH
13	W36-1202	WORM SHAFT
15	W36-1401	A/R CAM SPRING A
16	W36-1502	STABILIZER BAR
17	W36-1601	STABILIZER BAR SCREW
18	W36-1751	OSC SLIDER BUSHING
19	W36-1802	OSC SLIDER
20	W42-9401	BALL BEARING A
21	W36-2001	OSC SLIDER RET
22	W36-2102	OSC PAWL
23	W36-2202	OSC PAWL COLLAR
24	W36-2301	OSC PAWL WASHER
25	W36-2402	OSC SLIDER COVER
26	W36-2501	OSC SLIDER COVER SCREW
27	W36-2601	WORM SHAFT GEAR RET
28	W50-2701	WORM SHAFT GEAR
29	W42-9302	BALL BEARING B
30	W36-2901	A/R PAWL SPRING A
31	W50-2501	DRIVE GEAR
32	W36-3101	DRIVE GEAR WASHER
33	W42-9302	BALL BEARING C
34	W52-3203	SIDE COVER
35	W36-3301	SIDE COVER SCREW A
36	W36-3401	SIDE COVER SCREW B
37	W52-5901	HANDLE

Key		
No.	Parts No.	Parts Name
38	W36-3602	A/R PAWL A
39	W36-3702	A/R PAWL COLLAR
41	W36-3901	A/R PAWL SPRING B
42	W36-4001	A/R PAWL B
43	W36-4101	A/R PAWL B SCREW
44	W36-4201	REAR COVER SCREW B
45	W36-4302	A/R CAM
46	W36-4401	PINION RET
49	W42-9202	BALL BEARING D
50	W50-2601	PINION GEAR
51	W36-4901	PINION GEAR COLLAR
52	W36-5001	PINION WASHER
53	W36-5101	ROLLER CLUTCH
54	W36-5201	ROLLER CLUTCH WASHER
55	W36-5301	ROLLER CLUTCH COLLAR
56	W36-5401	BEARING RET A
57	W42-9201	BALL BEARING E
58	W36-5501	BALL BEARING RET WASHER
59	W36-5601	BEARING RET B
60	W36-5701	BEARING RET B SCREW
61	W36-5801	BALL BEARING F
62	W36-5902	BALL BEARING COLLAR A
63	W36-6001	SPACING SLEEVE
64	W36-6101	MAIN SHAFT SPRING A
65	W36-6202	MAIN SHAFT COLLAR
66	W36-5801	BALL BEARING G
67	W36-6301	BALL BEARING WASHER A
68	W36-6402	BALL BEARING WASHER B
69	W36-6501	MAIN SHAFT SPRING B
70	W36-6601	BAIL TRIP LEVER SCREW
71	W31-1801	BAIL TRIP LEVER WASHER
72	W36-6802	BAIL TRIP LEVER
73	W36-6901	BAIL TRIP LEVER SPRING
74	W36-7001	BAIL SPRING HOLDER
75	W36-7101	BAIL SPRING
76	W36-7202	BAIL SPRING SHAFT

Key		
No.	Parts No.	Parts Name
77	W52-6001	BAIL SPRING COVER
78	W36-7401	BAIL SPRING COVER SCREW
79	W36-7501	BAIL ARM SCREW
80	W36-7601	LINE ROLLER SCREW
81	W52-3403	BAIL ARM
82	W30-6201	LINE ROLLER WASHER A
83	W30-6101	LINE ROLLER WASHER A
84	W36-8051	LINE ROLLER COLLAR
85	W36-8101	LINE ROLLER
86	W52-3503	BAIL
87	W52-3603	ROTOR
89	W36-8401	BAIL HOLDER SCREW
90	W52-6101	COVER
91	W36-8601	BAIL HOLDER COVER SCREW
92	W36-8702	MAIN SHAFT NUT
93	W36-8801	ROTOR NUT HOLD PLT
94	W36-8901	ROTOR NUT HOLD PLT SCREW
95	W36-9002	MAIN SHAFT
96	W36-9102	LINE GUARD
97	W36-9201	CLICK GEAR
98	W36-9301	CLICK GEAR WASHER
99-103	W52-3703	SPOOL
100	W36-9601	DRAG WASHER
101	W36-9701	KEY WASHER
102	W36-9801	EARED WASHER
103	W36-9901	DRAG WASHER RET
104	W52-6201	DRAG KNOB
105	W34-3101	SIDE COVER SCREW C
106	W50-2901	ROLLER CLUTCH COVER
107	W50-3001	CLUTCH COVER SCREW
108	W50-3101	SPOOL WASHER
109	W50-3201	A/R CAM SPRING B

ECS5000 Special Parts

99-103	W52-3903	SPOOL
--------	----------	-------