


SPINNING REEL EXCELER 2500



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	G70-0801	DRAG KNOB	35	G53-9201	ROLLER CLUTCH
2	F88-4001	DRAG WASHER RET	36	G71-6201	SPACING SLEEVE
3	G70-0601	KEY WASHER	37	G46-7402	BEARING RET
4	F69-1001	DRAG WASHER	38	375-8509	BEARING RET WASHER
5	G70-0701	EARED WASHER	39	G53-5101	BALL BEARING B
2-6	G70-0301	SPOOL	40	G69-8901	PINION GEAR
2-6	G75-9701	SPOOL (EXTRA)	41	G69-8201	BODY
7	E46-7101	SPOOL WASHER	42	G69-8601	A/R CAM
8	G70-0001	CLICK LEAF SPRING HOLDER	43	G69-9402	A/R LEVER
9	E24-6101	CLICK LEAF SPRING WASHER	44	G69-9501	A/R LEVER SCREW
10	F70-4901	SPOOL CLICK LEAF SPRING	45	G72-6201	A/R CAM SPRING
11	G69-8701	MAIN SHAFT	46	G69-9301	REAR COVER
12	G69-9801	ROTOR NUT	47	E11-9602	REAR COVER SCREW A
13	G69-9701	ROTOR NUT COLLAR	48	G33-2702	REAR COVER SCREW B
14	G61-2010	ROTOR	49	G61-0802	STABILIZER BAR
15	G62-7701	ROTOR NUT LOCK SCREW	50	G61-0201	OSC GEAR
16	G19-5602	LINE ROLLER SCREW	51	G46-6001	O RING A
17	G61-2310	BAIL ARM	52	G46-6100	OSC GEAR WASHER
18	G20-5001	BAIL ARM SCREW	53	F05-5602	BALL BEARING C
19	F89-7101	LINE ROLLER WASHER	54	F20-6902	OSC GEAR SCREW
20	G28-1601	BALL BEARING A	55	G67-0501	O RING B
21	F62-5001	LINE ROLLER	56	G69-9001	DRIVE GEAR
22	G70-3401	BAIL	57	375-8500	DRIVE GEAR WASHER
23	G47-1801	BAIL SPRING SHAFT	58	G46-7302	BALL BEARING D
24	E31-3901	BAIL SPRING WASHER	59	G69-9101	SIDE COVER
25	G47-1701	BAIL SPRING	60	G33-2902	SIDE COVER SCREW
26	G61-2101	BAIL SPRING HOLDER	62	G69-9901	HANDLE
27	G61-2501	BAIL SPRING COVER	63	F01-6401	BALL BEARING E
28	G27-0801	BAIL SPRING COVER SCREW	64	G47-2401	BALL BEARING RET
29	G61-3201	BAIL TRIP LEVER COVER	65	F72-1001	HANDLE COLLAR
30	G61-3001	BAIL TRIP LEVER	66	160-8101	LOCK WASHER
31	G61-3101	BAIL TRIP LEVER SPRING	67	G70-0201	HANDLE SCREW
32	G61-1201	ROLLER CLUTCH RET	68	F70-1801	LINE ROLLER COLLAR
33	G55-7101	ROLLER CLUTCH RET SCREW	69	G55-7101	BEARING RET SCREW
34	G46-5401	CLUTCH CAM RET			