


FLY REEL **730**



Key No.	Parts No.	Parts Name
1	6-130-4701	Cover
2	6-144-1801	Spool stopper spring
3	6-541-3401	Spool stopper
4	6-B05-5001	Cover screw
5	6-375-3801	Cover washer
6	6-734-6501	Spool
7	6-701-6401	Body
8	6-030-6901	Click claw
9	6-310-2201	Line guard
10	6-350-8912	Line guard screw