




18 FREAMS LT 3000D-C

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



S40401J	18 FREAMS LT 2500D
S40402J	18 FREAMS LT 2500S-XH
S40403J	18 FREAMS LT 2500S-DH
S40501J	18 FREAMS LT 3000D-C
S40502J	18 FREAMS LT 3000S-CXH
S40601J	18 FREAMS LT 3000

S40701J	18 FREAMS LT 4000D-C
S40702J	18 FREAMS LT 4000D-CXH
S40801J	18 FREAMS LT 5000D-C
S40802J	18 FREAMS LT 5000D-CXH
S40901J	18 FREAMS LT 6000D-H

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
18 FREAMS LT 3000D-C	S40501J	1	6Q346201	DRAG KNOB
18 FREAMS LT 3000D-C	S40501J	2	6Q346101	DRAG RING
18 FREAMS LT 3000D-C	S40501J	3	6J547001	DRAG DISK WASHER
18 FREAMS LT 3000D-C	S40501J	4	6J546801	ATD WASHER ASSY (1pack-3 pcs)
18 FREAMS LT 3000D-C	S40501J	5	6Q346001	DRAG LIP WASHER
18 FREAMS LT 3000D-C	S40501J	6	6Q361301	SPOOL ASSY (2-6)
18 FREAMS LT 3000D-C	S40501J	7	6E398000	SPOOL WASHER (A)
18 FREAMS LT 3000D-C	S40501J	8	6Q348502	SPOOL WASHER (B)
18 FREAMS LT 3000D-C	S40501J	9	6J525101	CLICK LEAF SPRING
18 FREAMS LT 3000D-C	S40501J	10	6J546201	CLICK HOLDER
18 FREAMS LT 3000D-C	S40501J	11	6Q344001	CLICK HOLDER WASHER
18 FREAMS LT 3000D-C	S40501J	12	6H986901	ROTOR NUT PACKING
18 FREAMS LT 3000D-C	S40501J	13	6Q177001	ROTOR NUT
18 FREAMS LT 3000D-C	S40501J	14	6H022701	ROTOR NUT SCREW
18 FREAMS LT 3000D-C	S40501J	15	6Q120512	ROTOR
18 FREAMS LT 3000D-C	S40501J	16	6H413601	KICK LEVER SPRING
18 FREAMS LT 3000D-C	S40501J	17	6Q120701	KICK LEVER ASSY
18 FREAMS LT 3000D-C	S40501J	18	6H417701	KICK LEVER SCREW
18 FREAMS LT 3000D-C	S40501J	19	6Q121201	ARM LEVER SHAFT
18 FREAMS LT 3000D-C	S40501J	20	6H576101	ARM LEVER SHAFT PLATE
18 FREAMS LT 3000D-C	S40501J	21	6H545701	ARM LEVER SPRING
18 FREAMS LT 3000D-C	S40501J	22	6Q121501	ARM LEVER SPRING HOLDER
18 FREAMS LT 3000D-C	S40501J	23	6Q121801	ARM LEVER SPRING COVER
18 FREAMS LT 3000D-C	S40501J	24	6Q342901	ARM LEVER SPRING COVER SCREW
18 FREAMS LT 3000D-C	S40501J	25	6Q121611	ARM LEVER
18 FREAMS LT 3000D-C	S40501J	26	6Q121701	ARM LEVER SCREW COLLAR
18 FREAMS LT 3000D-C	S40501J	27	6Q343401	ARM LEVER SCREW
18 FREAMS LT 3000D-C	S40501J	28	6G195602	ROLLER SCREW
18 FREAMS LT 3000D-C	S40501J	29	6G195501	ROLLER COLLAR (A)
18 FREAMS LT 3000D-C	S40501J	30	6G220701	ROLLER COLLAR (B)
18 FREAMS LT 3000D-C	S40501J	31	6J089901	LINE ROLLER
18 FREAMS LT 3000D-C	S40501J	32	6Q203401	ROLLER COLLAR (C)
18 FREAMS LT 3000D-C	S40501J	33	6Q121901	BAIL ASSY
18 FREAMS LT 3000D-C	S40501J	34	6G837101	MAGSEALED PLATE SCREW
18 FREAMS LT 3000D-C	S40501J	35	63754102	MAGSEALED PLATE SCREW WASHER
18 FREAMS LT 3000D-C	S40501J	36	6J354401	MAGSEALED PLATE
18 FREAMS LT 3000D-C	S40501J	37	6J354801	MAGSEALED PLATE O-RING
18 FREAMS LT 3000D-C	S40501J	38	-----	
18 FREAMS LT 3000D-C	S40501J	39	6Q266601	MAGSEALED CAP
18 FREAMS LT 3000D-C	S40501J	40	6J388401	ONEWAY CLUTCH
18 FREAMS LT 3000D-C	S40501J	41	6J001402	CLUTCH RING
18 FREAMS LT 3000D-C	S40501J	42	6Q126201	PINION BEARING PLATE SCREW
18 FREAMS LT 3000D-C	S40501J	43	6Q195601	PINION BEARING PLATE
18 FREAMS LT 3000D-C	S40501J	44	6G467302	PINION BALL BEARING (A)
18 FREAMS LT 3000D-C	S40501J	45	63758500	PINION BEARING WASHER (A)
18 FREAMS LT 3000D-C	S40501J	46	6Q341701	PINION GEAR
18 FREAMS LT 3000D-C	S40501J	47	6H931701	PINION BEARING SPRING WASHER (B)
18 FREAMS LT 3000D-C	S40501J	48	6H959601	PINION BALL BEARING (B)
18 FREAMS LT 3000D-C	S40501J	49	6Q364901	BODY ASSY
18 FREAMS LT 3000D-C	S40501J	50	6Q341501	MAIN SHAFT
18 FREAMS LT 3000D-C	S40501J	51	6Q126301	OSCILLATING POST (A)
18 FREAMS LT 3000D-C	S40501J	52	6Q119101	OSCILLATING POST (B)
18 FREAMS LT 3000D-C	S40501J	53	6Q118101	STOPPER CAM
18 FREAMS LT 3000D-C	S40501J	54	6H697801	STOPPER CAM SPRING
18 FREAMS LT 3000D-C	S40501J	55	6Q118001	STOPPER LEVER
18 FREAMS LT 3000D-C	S40501J	56	6Q342801	REAR CAP
18 FREAMS LT 3000D-C	S40501J	57	6Q342901	REAR CAP SCREW
18 FREAMS LT 3000D-C	S40501J	58	6H595701	OSCILLATING GEAR WASHER
18 FREAMS LT 3000D-C	S40501J	59	6Q118401	OSCILLATING GEAR
18 FREAMS LT 3000D-C	S40501J	60	6H770601	OSCILLATING GEAR O-RING
18 FREAMS LT 3000D-C	S40501J	61	6H129200	OSCILLATING GEAR BALL BEARING WASHER
18 FREAMS LT 3000D-C	S40501J	62	6G469005	OSCILLATING GEAR BALL BEARING
18 FREAMS LT 3000D-C	S40501J	63	6Q126101	OSCILLATING GEAR SCREW
18 FREAMS LT 3000D-C	S40501J	64	6G670501	DRIVE GEAR O-RING
18 FREAMS LT 3000D-C	S40501J	65	6Q341801	DRIVE GEAR
18 FREAMS LT 3000D-C	S40501J	66	63758500	DRIVE GEAR BALL BEARING WASHER
18 FREAMS LT 3000D-C	S40501J	67	6G467302	DRIVE GEAR BALL BEARING (A)
18 FREAMS LT 3000D-C	S40501J	68	6Q342401	BODY COVER
18 FREAMS LT 3000D-C	S40501J	69	6Q342701	BODY COVER SCREW(A)
18 FREAMS LT 3000D-C	S40501J	70	6Q342601	BODY COVER SCREW(B)
18 FREAMS LT 3000D-C	S40501J	71	6J100201	HANDLE PACKING
18 FREAMS LT 3000D-C	S40501J	72	6Q361601	HANDLE ASSY
18 FREAMS LT 3000D-C	S40501J	73	6G522706	DRIVE GEAR BALL BEARING (B)
18 FREAMS LT 3000D-C	S40501J	74	6G472401	DRIVE GEAR BALL BEARING (B) RING
18 FREAMS LT 3000D-C	S40501J	75	6G162401	HANDLE CAP O-RING
18 FREAMS LT 3000D-C	S40501J	76	6Q345101	HANDLE CAP
18 FREAMS LT 3000D-C	S40501J	200	6Q361701	HANDLE KNOB
18 FREAMS LT 3000D-C	S40501J	201	6G720001	HANDLE KNOB BEARING
18 FREAMS LT 3000D-C	S40501J	202	6B679308	HANDLE KNOB SCREW
18 FREAMS LT 3000D-C	S40501J	203	6Q361901	HANDLE KNOB CAP