




21 FREAMS LT 3000

Feel Alive.


Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



- 21 FREAMS FC LT 1000S
- 21 FREAMS FC LT 2000S
- 21 FREAMS FC LT 2000S-XH
- 21 FREAMS LT 2500
- 21 FREAMS LT 2500-XH

- S4010YJ S4050XJ S4070YJ
- S4020XJ S4050YJ S4080XJ
- S4020YJ S4060XJ S4090XJ
- S4040XJ S4060YJ
- S4040YJ S4070XJ

- 21 FREAMS LT 3000-CXH
- 21 FREAMS LT 3000-C
- 21 FREAMS LT 3000-XH
- 21 FREAMS LT 3000
- 21 FREAMS LT 4000-CXH
- 21 FREAMS LT 4000-C
- 21 FREAMS LT 5000-CXH
- 21 FREAMS LT 6000D-H



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 FREAMS LT 3000		1	6Q346201	DRAG KNOB
21 FREAMS LT 3000		2	6Q346101	DRAG WASHER RETAINER
21 FREAMS LT 3000		3	6Q621901	KEY WASHER
21 FREAMS LT 3000		4	6J546801	DRAG WASHER
21 FREAMS LT 3000		5	6Q346001	EARED WASHER
21 FREAMS LT 3000		6	6Q706101	SPOOL ASSY (2-6)
21 FREAMS LT 3000		7	6E398003	SPOOL WASHER (A)
21 FREAMS LT 3000		8	6Q348502	SPOOL WASHER (B)
21 FREAMS LT 3000		9	6H416101	CLICK LEAF SPRING
21 FREAMS LT 3000		10	6M021401	CLICK SPRING HOLDER
21 FREAMS LT 3000		11	6Q344001	SPOOL WASHER (C)
21 FREAMS LT 3000		12	6H986901	ROTOR NUT PACKING
21 FREAMS LT 3000		13	6Q177001	ROTOR NUT
21 FREAMS LT 3000		14	6H022701	ROTOR NUT SCREW
21 FREAMS LT 3000		15	6Q120535	ROTOR
21 FREAMS LT 3000		16	6H413601	BAIL TRIP LEVER SPRING
21 FREAMS LT 3000		17	6Q120701	BAIL TRIP LEVER
21 FREAMS LT 3000		18	6H417701	BAIL TRIP LEVER SCREW
21 FREAMS LT 3000		19	6Q121201	ARM LEVER SHAFT
21 FREAMS LT 3000		20	6H576101	ARM LEVER SHAFT PLATE
21 FREAMS LT 3000		21	6H545701	ARM LEVER SPRING
21 FREAMS LT 3000		22	6Q121501	ARM LEVER SPRING HOLDER
21 FREAMS LT 3000		23	6Q121801	ARM LEVER COVER
21 FREAMS LT 3000		24	6Q342901	ARM LEVER COVER SCREW
21 FREAMS LT 3000		25	6Q121623	ARM LEVER
21 FREAMS LT 3000		26	6Q121701	ARM LEVER SCREW COLLAR
21 FREAMS LT 3000		27	6Q343401	ARM LEVER SCREW
21 FREAMS LT 3000		28	6G195602	ROLLER SCREW
21 FREAMS LT 3000		29	6G195501	ROLLER COLLAR (A)
21 FREAMS LT 3000		30	6G220701	ROLLER COLLAR (B)
21 FREAMS LT 3000		31	6J089902	LINE ROLLER
21 FREAMS LT 3000		32	6Q203401	ROLLER COLLAR (C)
21 FREAMS LT 3000		33	6Q777101	BAIL
21 FREAMS LT 3000		34	6G837101	MAGSEALED PLATE SCREW
21 FREAMS LT 3000		35	63754102	MAGSEALED PLATE SCREW WASHER
21 FREAMS LT 3000		36	6J688201	MAGSEALED PLATE
21 FREAMS LT 3000		37	6J354801	MAGSEALED O RING
21 FREAMS LT 3000		38	-----	---
21 FREAMS LT 3000		39	6Q266601	MAGSEALED CAP
21 FREAMS LT 3000		40	6J388401	ONEWAY CLUTCH
21 FREAMS LT 3000		41	6J001403	CLUTCH RING
21 FREAMS LT 3000		42	6Q126201	PINION BEARING PLATE SCREW
21 FREAMS LT 3000		43	6Q195601	PINION BEARING PLATE
21 FREAMS LT 3000		44	6G535104	PINION BALL BEARING (A)
21 FREAMS LT 3000		45	63758502	PINION BEARING WASHER
21 FREAMS LT 3000		46	6Q351201	PINION GEAR
21 FREAMS LT 3000		47	6H931701	PINION SPRING WASHER
21 FREAMS LT 3000		48	6G466202	PINION BALL BEARING (B)
21 FREAMS LT 3000		49	-----	---
21 FREAMS LT 3000		50	6Q705101	BODY
21 FREAMS LT 3000		51	6Q381701	MAIN SHAFT
21 FREAMS LT 3000		52	6Q126302	OSCILLATING POST (A)
21 FREAMS LT 3000		53	6Q119102	OSCILLATING POST (B)
21 FREAMS LT 3000		54	6Q118101	ANTI REVERSE CAM

