



| Key No. | Parts No. | Parts Name |
|---------|-----------|--------------------------|
| 1 | F09-9403 | L/S OUTER RING |
| 2 | F09-3602 | L/S PLT SCREW |
| 3 | F78-8503 | L/S PLT |
| 4 | E36-1302 | CLICK BUTTON |
| 5 | 373-1602 | CLICK BUTTON WASHER |
| 6 | 030-6222 | CLICK PAWL |
| 7 | 320-1402 | CLICK PAWL RET |
| 8 | F13-2602 | SPACER A |
| 9 | 375-7411 | BEARING WASHER A |
| 10 | 160-7922 | CLICK SPRING |
| 11 | F13-1801 | CLICK SPRING RET |
| 12 | B83-4402 | CLICK SPRING SCREW |
| 13 | G28-9901 | SPOOL |
| 14 | 637-2101 | BALL BEARING A |
| 15 | B35-2801 | BRAKE COLLAR A |
| 16 | B35-2701 | BRAKE COLLAR B |
| 18 | F73-6804 | STABILIZER BAR |
| 19 | F77-4701 | COLLAR A |
| 20 | F21-6201 | BEARING RET A |
| 21 | F05-5503 | BALL BEARING B |
| 22 | F94-7101 | SPACER B |
| 23 | G28-9701 | FRAME |
| 24 | F09-7901 | YOKE PLT |
| 25 | E25-2102 | YOKE |
| 26 | E03-7706 | YOKE WASHER |
| 27 | F93-5201 | YOKE SPRING |
| 28 | F09-8201 | A/R PAWL PIN |
| 29 | F77-4401 | A/R PAWL SPRING |
| 30 | F73-3401 | A/R PAWL |
| 31 | F94-7201 | PINION GEAR |
| 32 | B09-5601 | BEARING RET B |
| 33 | F79-8402 | BALL BEARING C |
| 34 | F09-7301 | CLUTCH CAM |
| 35 | F38-5801 | CLUTCH SPRING |
| 36 | F94-6704 | R/S PLT |
| 37 | E42-6812 | CLUTCH LEVER |
| 38 | 160-8001 | CLUTCH LEVER LOCK WASHER |
| 39 | E00-7601 | CLUTCH LEVER SCREW |
| 40 | F09-7204 | R/S OUTER RING |
| 41 | F09-3602 | R/S PLT SCREW A |
| 42 | F73-4301 | R/S PLT SCREW B |
| 43 | B05-5201 | O RING A |
| 44 | F94-6901 | PINION SHAFT |
| 45 | F73-2801 | PIN |
| 46 | 375-7501 | SPACER C |
| 47 | B17-5503 | SPACER D |

Indicate parts number reversed

| Key No. | Parts No. | Parts Name |
|---------|-----------|--------------------------|
| 48 | E31-5403 | CAST CONTROL CAP |
| 49 | F73-3501 | DRIVE SHAFT WASHER A |
| 50 | B73-8001 | BUSHING |
| 51 | G29-1001 | DRIVE SHAFT |
| 52 | F09-8401 | DRIVE SHAFT RET |
| 53 | E31-6701 | DRIVE SHAFT RET SCREW |
| 54 | F65-7801 | O RING B |
| 55 | F55-5102 | A/R RATCHET |
| 56 | F73-3701 | DRIVE SHAFT WASHER B |
| 57 | F73-3801 | DRIVE GEAR |
| 58 | F87-7501 | DRAG WASHER |
| 59 | E31-7001 | KEY WASHER |
| 60 | E31-7101 | EARED WASHER |
| 61 | F65-7801 | O RING C |
| 62 | F73-3901 | WATER SHIELD |
| 63 | F94-7401 | COLLAR B |
| 64 | F82-7801 | HANDLE METAL PLT |
| 65 | E24-8101 | HANDLE METAL PLT SCREW |
| 66 | F82-7101 | SPACING SLEEVE |
| 67 | F82-7601 | HANDLE METAL |
| 68 | F36-6802 | HANDLE METAL COLLAR |
| 69 | F05-5502 | BALL BEARING D |
| 70 | F36-6803 | BEARING WASHER B |
| 71 | E25-3501 | DRAG SPRING WASHER |
| 72 | F17-0501 | CLICK LEAF SPRING HOLDER |
| 73 | B74-7702 | CLICK LEAF SPRING |
| 74 | F55-0419 | STAR DRAG |
| 75 | E25-3901 | FRICTION WASHER |
| 76 | F97-6001 | HANDLE |
| 77 | B86-2102 | HANDLE NUT |
| 78 | F47-1207 | HANDLE NUT PLT |
| 79 | F18-7701 | ROD BRACE NUT |
| 80 | 041-5601 | ROD CLAMP |
| 81 | F18-7801 | CLAMP NUT |
| 82 | F18-7601 | CLAMP BOLT |

GW-Z50HW SPECIAL PARTS

| Key No. | Parts No. | Parts Name |
|---------|-----------|----------------|
| 3 | F78-8504 | L/S PLT |
| 13 | G29-0101 | SPOOL |
| 18 | F09-9304 | STABILIZER BAR |
| 23 | G29-0001 | FRAME |
| 36 | F94-6705 | R/S PLT |
| 83 | E31-8302 | ROD CLAMP |
| 84 | E31-8401 | CLAMP BOLT |

(*) Parts for GW-Z40HW only