



Key No.	Parts No.	Parts Name
1	F09-9403	L/S OUTER RING
2	F09-3602	L/S PLT SCREW
3	F78-8503	L/S PLT
4	E36-1302	CLICK BUTTON
5	373-1602	CLICK BUTTON WASHER
6	030-6222	CLICK PAWL
7	320-1402	CLICK PAWL RET
8	F13-2602	SPACER A
9	375-7411	BEARING WASHER A
10	160-7922	CLICK SPRING
11	F13-1801	CLICK SPRING RET
12	B83-4402	CLICK SPRING SCREW
13	G28-9901	SPOOL
14	637-2101	BALL BEARING A
15	B35-2801	BRAKE COLLAR A
16	B35-2701	BRAKE COLLAR B
18	F73-6804	STABILIZER BAR
19	F77-4701	COLLAR A
20	F21-6201	BEARING RET A
21	F05-5503	BALL BEARING B
22	F94-7101	SPACER B
23	G28-9701	FRAME
24	F09-7901	YOKE PLT
25	E25-2102	YOKE
26	E03-7706	YOKE WASHER
27	F93-5201	YOKE SPRING
28	F09-8201	A/R PAWL PIN
29	F77-4401	A/R PAWL SPRING
30	F73-3401	A/R PAWL
31	F94-7201	PINION GEAR
32	B09-5601	BEARING RET B
33	F79-8402	BALL BEARING C
34	F09-7301	CLUTCH CAM
35	F38-5801	CLUTCH SPRING
36	F94-6704	R/S PLT
37	E42-6812	CLUTCH LEVER
38	160-8001	CLUTCH LEVER LOCK WASHER
39	E00-7601	CLUTCH LEVER SCREW
40	F09-7204	R/S OUTER RING
41	F09-3602	R/S PLT SCREW A
42	F73-4301	R/S PLT SCREW B
43	B05-5201	O RING A
44	F94-6901	PINION SHAFT
45	F73-2801	PIN
46	375-7501	SPACER C
47	B17-5503	SPACER D

Indicate parts number reversed

Key No.	Parts No.	Parts Name
48	E31-5403	CAST CONTROL CAP
49	F73-3501	DRIVE SHAFT WASHER A
50	B73-8001	BUSHING
51	G29-1001	DRIVE SHAFT
52	F09-8401	DRIVE SHAFT RET
53	E31-6701	DRIVE SHAFT RET SCREW
54	F65-7801	O RING B
55	F55-5102	A/R RATCHET
56	F73-3701	DRIVE SHAFT WASHER B
57	F73-3801	DRIVE GEAR
58	F87-7501	DRAG WASHER
59	E31-7001	KEY WASHER
60	E31-7101	EARED WASHER
61	F65-7801	O RING C
62	F73-3901	WATER SHIELD
63	F94-7401	COLLAR B
64	F82-7801	HANDLE METAL PLT
65	E24-8101	HANDLE METAL PLT SCREW
66	F82-7101	SPACING SLEEVE
67	F82-7601	HANDLE METAL
68	F36-6802	HANDLE METAL COLLAR
69	F05-5502	BALL BEARING D
70	F36-6803	BEARING WASHER B
71	E25-3501	DRAG SPRING WASHER
72	F17-0501	CLICK LEAF SPRING HOLDER
73	B74-7702	CLICK LEAF SPRING
74	F55-0419	STAR DRAG
75	E25-3901	FRICITION WASHER
76	F97-6001	HANDLE
77	B86-2102	HANDLE NUT
78	F47-1207	HANDLE NUT PLT
79 *	F18-7701	ROD BRACE NUT
80 *	041-5601	ROD CLAMP
81 *	F18-7801	CLAMP NUT
82 *	F18-7601	CLAMP BOLT

GW-Z50HW SPECIAL PARTS

Key No.	Parts No.	Parts Name
3	F78-8504	L/S PLT
13	G29-0101	SPOOL
18	F09-9304	STABILIZER BAR
23	G29-0001	FRAME
36	F94-6705	R/S PLT
83	E31-8302	ROD CLAMP
84	E31-8401	CLAMP BOLT

(*) Parts for GW-Z40HW only