




BAITCASTING REEL

Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)

LEXA-WN300HSL/HSL-P



Key No.	Part No.	Part Name	Key No.	Part No.	Part Name
1	460-5571	SET PLATE SCREW	50	200-1160	RETAINER
2	510-4450	SET PLATE SPRING	51	140-1280	BALL BEARING
3	550-1610	BRAKE ADJ KNOB	52	200-0580	RETAINER
4	510-5180	BRAKE CLICK SPRING	53	410-2550	PLATE
5	200-0530	RETAINER	54	470-1971	DRIVE SHAFT
6	540-5380	WASHER	55	540-6600	WASHER
7	230-238B	RIGHT SIDE PLATE	56	460-5370	SCREW
8	410-1911	BRAKE DIAL RETAINER	57	460-5290	SCREW
9	230-2390	SET PLATE	58	240-2200	OSC GEAR
10	460-3220	SET PLATE SCREW	59	540-7010	DRIVE SHAFT WASHER
11	240-1952	MAGNET HOLDER	60	530-0860	A/R PAWL
12	430-1070	MAGNET HOLDER RET	61	240-2550	A/R RATCHET
13	540-5990	SPACER	62	540-9830	WASHER
14	140-1500	BALL BEARING	63	250-1370	DRIVE GEAR
15	430-1061	BEARING RETAINER	64	540-6890	DRAG WASHER
16-19	701-2920	SPOOL ASSEMBLY	65	540-8010	KEY WASHER
20	110-1041	FRAME	66	540-8030	EARED WASHER
21	410-1960	SPACER	67	540-8080	WASHER
22	090-0280	CLUTCH LEVER	68	540-8020	KEY WASHER
23	410-1970	SPACER	69	150-2200	GEAR SHAFT COLLAR
24	400-2570	PIN	70	140-1370	ROLLER CLUTCH
25	170-1271	CLUTCH CAM	71	701-2940	LEFT SIDE PLATE
26	410-2620	PLATE	72	150-2060	BUSHING
27	400-3310	KICK LEVER PIN	73	430-1061	BEARING RETAINER
28	330-2850	KICK LEVER	74	430-1080	O-RING
29	200-0570	E-CLIP	75	540-6850	SPACER
30	460-1290	SCREW	76	540-4340	SPACER
31	510-5140	KICK LEVER SPRING	77	380-1791	CAST CONTROL CAP
32	510-5172	SPRING	78	460-4300	SCREW
33	410-2890	YOKE	79	460-1131	SIDE PLATE SCREW
34	540-6020	WASHER	80	140-0570	BALL BEARING
35	510-4430	YOKE SPRING	81	540-6250	WASHER
36	260-1763	PINION GEAR	82	510-5370	CLICK LEAF SPRING HOLDER
37	701-2820	LINE GUIDE	83	540-6391	WASHER
38	400-2540	LINE GUIDE PAWL	84	540-9021	WASHER
39	540-3980	WASHER	85	700-7180	STAR DRAG
40	380-0780	LINE GUIDE NUT	86	510-3260	LEAF SPRING
41	270-0810	LEVEL WIND GUARD	87	701-2930	HANDLE ASSEMBLY
42	470-1960	WORM SHAFT	88	380-2000	HANDLE NUT
43	240-2210	WORM SHAFT GEAR	89	350-0310	HANDLE NUT PLATE
44	200-0530	RETAINER	90	460-5390	HANDLE NUT PLATE SCREW
45	550-1641	FRONT PLATE			
46	540-6060	WORM SHAFT WASHER			
47	200-0530	WORM SHAFT RETAINER			
48	460-4980	LONG SCREW			
49	400-2660	PILLAR			

LEXA-WN300HSL-P SPECIAL PARTS		
Key No.	Part No.	Part Name
91	701-2980	LEFT SIDE PLATE
92	701-2970	HANDLE ASSEMBLY (PWR)