


DAIWA BAITCASTING REEL

LEXA - HD 500H-P / XH-P / -P / P-P

Please order by parts number, not key number



Key No	Part No	Description
1	460-5620	Set plate screw
2	510-4450	Set plate spring
3	550-1700	Brake adjusting knob
4	510-5341	Brake click spring
5	200-0530	Brake dial retained A)
6	540-5380	Washer
7	WE0-5601	Left side plate
8	410-2720	Brake dial retained B)
9	701-4560	Set plate
10	460-3220	Screw
11	701-5100	Magnet holder
12	430-1070	Magnet holder ret. Ring
13	540-8200	Washer
14	540-8110	Spacer(A)
15	140-3310	Ball bearing
16	430-0440	Bearing retainer
17-20,	WE0-5701	Spool assembly
21	410-2680	Spacer(B)
22	WE0-5801	Clutch lever
23	410-2670	Spacer (C)
24	WE0-5901	Frame
25	400-2570	Pin
26	510-5310	Spring
27	400-2720	Pin
28	170-1370	Clutch cam
29	WE0-6001	Plate
30	510-5300	Spring
31	460-1290	Screw
32	400-3310	Kick lever pin
33	330-2941	Kick lever
34	510-5292	Kick lever spring
35	210-2410	Bushing
36	200-0570	E-Clip
37	410-2712	Yoke
38	510-6040	Yoke spring
39	260-2203	Pinion gear
40	WE0-6101	Right side plate
41	460-5790	Screw
42	460-4870	Screw
43	460-7430	Screw
44	430-1061	Bearing retainer
45	150-2060	Bushing
46	430-1000	O-Ring
47	540-6460	Spacer(D)
48	540-5980	Spacer(E)
49	38A-1990	Cast control cap
50	200-0580	Worm shaft retainer
51	150-2260	Bushing
52	WE0-6201	Long screw
53	WE0-6301	Frame plate
54	701-3000	Line guide
55	E59-0601	Line guide paw
56	540-9950	Washer
57	380-0780	Line pawl cap
58	WE0-6401	Level wind guard
59	WE0-6501	Worm shaft

Key No	Part No	Description
60	150-1051	Bush
61	240-2300	Worm shaft gear
62	200-0530	Gear retainer
63	WE0-6601	Pillar
64	200-1160	E-Oip
65	140-2180	Ball bearing
66	540-7350	Washer
67	200-0580	Drive gear shaft retainer
68	410-2700	Plate
69	460-5290	Screw
70	460-5370	Screw
71	541-1650	Washer
72	240-2260	Oscillation gear
73	470-2491	Drive shaft
74	530-0860	Anti-reverse pawl
75	240-3030	Anti-reverse ratchet
76	540-6670	Spacer (F)
77	250-1700	Drive gear
78	540-7100	Washer
79	540-8060	Washer
80	540-9890	Drag washer
81	540-8100	Key washer
82	540-8090	Drag washer
83	540-8070	Top washer
84	150-2270	Gear shaft collar
85	140-2000	Roller clutch
86	140-2130	Ball bearing
87	540-1480	Spacing washer
88	510-5370	Plate
89	540-6391	Drag spring washer
90	540-9021	Washer
91	380-3211	Nut
92	510-6130	Spring
93	32A-1330	Star drag
94	540-9301	Washer
95	540-9271	Washer
96	702-1780	Handle assembly
97	380-1441	Handle nut
98	41A-2500	Handle nut plate
99	460-8240	Screw
100	540-6340	Washer

LX HD 500 XH-P Special Parts

39	260-2233	Pinion gear
40	WE0-6102	Right side plate
77	250-1720	Drive gear

LX HD 500 -P Special Parts

39	260-2302	Pinion gear
40	WE0-6103	Right side plate
77	250-1790	Drive gear

LX HD 500 P-P Special Parts

39	260-2312	Pinion gear
40	WE0-6104	Right side plate
77	250-1800	Drive gear