


Please order by parts number, not key number
Veuillez indiquer le numéro de la pièce (Non "Key" No.)



LEXA 300H/300HS/300HS-P/300PWR



KEY NO.	PART NO.	PART NAME	KEY NO.	PART NO.	PART NAME
1	460-5570	SET PLATE SCREW	57	240-2200	DRIVE SHAFT GEAR
2	510-4450	SET PLATE SPRING	58	540-7010	DRIVE SHAFT WASHER B
3	550-1611	BRAKE ADJUST KNOB	59	240-2550	ANTI-REVERSE RATCHET
4	510-5180	BRAKE CLICK SPRING	60	530-0860	ANTI-REVERSE PAWL
5	200-0530	BRAKE DIAL RETAINER(A)	61	250-1340	DRIVE GEAR
6	230-2350	LEFT SIDE PLATE	62	540-6890	DRAG WASHER
7	410-1911	BRAKE DIAL RETAINER(B)	63	540-8010	KEY WASHER
8	230-2360	SET PLT	64	150-2200	GEAR SHAFT COLLAR
9	460-3220	SCREW	65	140-1370	ROLLER CLUTCH
10	240-1952	MAGNET HOLDER	66	140-0570	BALL BEARING
11	430-1070	MAGNET HOLDER RET. RING	67	540-1570	SPACING WASHER
12	540-5990	SPACER(A)	68	410-2220	CLICK LEAF SPRING HOLDER
13	140-1500	BALL BEARING(A)	69	510-4760	LEAF SPRING(A)
14	430-1061	BEARING RETAINER	70	540-6390	DRAG SPRING WASHER
15-17	700-9510	SPOOL ASSEMBLY	71	700-7170	STAR DRAG
18	410-1970	SPACER(B)	72	510-3260	LEAF SPRING(B)
19	090-0280	CLUTCH LEVER	73	700-8440	HANDLE ASSEMBLY
20	410-1960	SPACER(C)	74	380-0770	HANDLE NUT
21	110-1030	FRAME ASSEMBLY	75	180-2471	HANDLE NUT PLATE
22	200-0530	WORM SHAFT RETAINER	76	460-0440	SCREW
23	400-2250	SPOOL PIN	77	430-1080	D-RING
24	540-6060	WORM SHAFT WASHER	78	540-9020	WASHER(D)
25	170-1261	CLUTCH CAM	79	400-3310	KICK LEVWE PIN
26	410-2610	CLUTCH CAM PLT	80	330-2840	KICK LEVER
27	510-5160	SPRING	81	510-5130	KICK LEVER SPRING
28	460-1290	SCREW	82	200-0570	E-CLIP
29	460-5370	SEREW	83	400-2660	PILLAR
30	410-1890	YOKE	84	200-1160	E-CLIP
31	510-5190	YOKE SPRING	85	400-2570	PIN
32	540-6020	WASHER	86	540-8030	EARED WASHER
33	260-1730	PINION GEAR	87	540-8020	TOP WASHER
34	430-1061	BEARING RETAINER	88	540-7030	WASHER
35	150-2060	BUSH	89	540-8080	WASHER
36	230-2340	RIGHT SIDE PLATE	90	540-5380	WASHER
37	460-7010	SCREW	91	540-6600	WASHER
38	460-5600	SCREW			
39	540-6850	SPACER(D)			
40	540-4340	SPACER(E)			
41	380-1661	CAST CONTROL CAP			
42	460-4980	LONG SCREW			
43	490-1080	LINE GUIDE			
44	400-2540	LINE GUIDE PAWL			
45	540-3980	WASHER(C)			
46	380-0780	LINE PAWL CAP			
47	270-0810	LEVEL WIND GUARD			
48	470-1960	WORM SHAFT			
49	240-2210	WORM SHAFT GEAR			
50	200-0530	GEAR RETANER			
51	550-1630	FRAME PLATE			
52	140-1280	BALL BEARING			
53	200-0580	DRIVE GEAR SHAFT RETAINER(B)			
54	410-2540	DRIVE SHAFT RETAINER			
55	460-5290	SCREW			
56	470-1950	DRIVE SHAFT			

LEXA 300HS SPECIAL PARTS		
KEY NO.	PART NO.	PART NAME
33	260-1740	PINION GEAR
36	230-2341	RIGHT SIDE PLATE
61	250-1350	DRIVE GEAR

LEXA 300HS-P SPECIAL PARTS		
KEY NO.	PART NO.	PART NAME
33	260-1741	PINION GEAR
36	230-2342	RIGHT SIDE PLATE
61	260-1350	DRIVE GEAR
73	700-8450	HANDLE ASSEMBLY

LEXA 300 PWR SPECIAL PARTS		
KEY NO.	PART NO.	PART NAME
33	260-1940	PINION GEAR
36	230-2343	RIGHT SIDE PLATE
61	250-1500	DRIVE GEAR