




# 20 LUVIAS LT 3000-XH

**Feel Alive.**

Please quote by part number, not key number when ordering.  
spares@daiwaaustralia.com.au PH: (02) 8644 8644

S42602J	20 LUVIAS LT 3000-XH
S42603J	20 LUVIAS LT 3000D
S42604J	20 LUVIAS LT 3000
S42702J	20 LUVIAS LT 4000-CXH
S42703J	20 LUVIAS LT 4000D-C
S42704J	20 LUVIAS LT 4000-C



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
20 LUVIAS LT 3000-XH		1	6J547201	DRAG KNOB
20 LUVIAS LT 3000-XH		2	6J547101	DRAG RING
20 LUVIAS LT 3000-XH		3	6J547001	DRAG DISC WASHER (A)
20 LUVIAS LT 3000-XH		4	6J546801	DRAG WASHER
20 LUVIAS LT 3000-XH		5	6J549001	DRAG LIP WASHER
20 LUVIAS LT 3000-XH		6	6J546902	DRAG DISC WASHER (B)
20 LUVIAS LT 3000-XH		7	-	
20 LUVIAS LT 3000-XH		8	6J546701	SPOOL COLLAR
20 LUVIAS LT 3000-XH		2~12	6J980701	SPOOL ASSY ( 2-12)
20 LUVIAS LT 3000-XH		10	6J558101	LINE STOPPER
20 LUVIAS LT 3000-XH		11	6J558001	LINE STOPPER PLATE
20 LUVIAS LT 3000-XH		12	6J314801	LINE STOPPER SPRING
20 LUVIAS LT 3000-XH		13	6J546301	SPOOL WASHER ( A )
20 LUVIAS LT 3000-XH		14	6J558201	SPOOL METAL SCREW
20 LUVIAS LT 3000-XH		15	6J549501	SPOOL METAL
20 LUVIAS LT 3000-XH		16	6H624801	SPOOL METAL COLLAR
20 LUVIAS LT 3000-XH		17	6I602201	SPOOL WASHER ( B )
20 LUVIAS LT 3000-XH		18	6M021401	CLICK HOLDER
20 LUVIAS LT 3000-XH		19	6H416101	CLICK LEAF SPRING
20 LUVIAS LT 3000-XH		20	6H986901	ROTOR NUT PACKING
20 LUVIAS LT 3000-XH		21	6H961101	ROTOR NUT
20 LUVIAS LT 3000-XH		22	6H022701	ROTOR NUT SCREW
20 LUVIAS LT 3000-XH		23	6J257101	ROTOR COVER
20 LUVIAS LT 3000-XH		24	6H022701	ROTOR COVER SCREW
20 LUVIAS LT 3000-XH		25	6J254307	ROTOR
20 LUVIAS LT 3000-XH		26	6J435201	KICK LEVER SPRING
20 LUVIAS LT 3000-XH		27	6J339502	KICK LEVER WASHER
20 LUVIAS LT 3000-XH		28	6J254401	KICK LEVER ASSY
20 LUVIAS LT 3000-XH		29	6H417701	KICK LEVER SCREW
20 LUVIAS LT 3000-XH		30	6J254601	ARM LEVER SHAFT
20 LUVIAS LT 3000-XH		31	6J254701	ARM LEVER SHAFT HOLDER
20 LUVIAS LT 3000-XH		32	-	
20 LUVIAS LT 3000-XH		33	6J255101	ARM LEVER SPRING COVER
20 LUVIAS LT 3000-XH		34	6J255201	COVER SCREW
20 LUVIAS LT 3000-XH		35	6J254807	ARM LEVER
20 LUVIAS LT 3000-XH		36	6J254901	ARM LEVER SCREW COLLAR
20 LUVIAS LT 3000-XH		37	6J255001	ARM LEVER SCREW
20 LUVIAS LT 3000-XH		38	6J257001	ROLLER SCREW
20 LUVIAS LT 3000-XH		39	6F897101	ROLLER WASHER
20 LUVIAS LT 3000-XH		40,49	6J736201	ROLLER COLLAR PACKING
20 LUVIAS LT 3000-XH		41,48	6J530401	ROLLER COLLAR (A)
20 LUVIAS LT 3000-XH		42,47	6J256702	ROLLER BALL BEARING
20 LUVIAS LT 3000-XH		43,46	6J530501	ROLLER COLLAR (B)
20 LUVIAS LT 3000-XH		44	6J256301	ROLLER COLLAR (C)
20 LUVIAS LT 3000-XH		45	6J256501	LINE ROLLER
20 LUVIAS LT 3000-XH		50	6J891101	BAIL ASSY
20 LUVIAS LT 3000-XH		51	6J254901	BAIL HOLDRE SCREW COLLAR
20 LUVIAS LT 3000-XH		52	6J255001	BAIL HOLDRE SCREW
20 LUVIAS LT 3000-XH		53	6G471803	BAIL SPRING SHAFT
20 LUVIAS LT 3000-XH		54	6G685401	BAIL SPRING SHAFT WASHER
20 LUVIAS LT 3000-XH		55	6J255301	BAIL SPRING
20 LUVIAS LT 3000-XH		56	6G471602	BAIL SPRING SHAFT HOLDER
20 LUVIAS LT 3000-XH		57	6J255901	BAIL HOLDER COVER
20 LUVIAS LT 3000-XH		58	6J255201	BAIL HOLDER COVER SCREW
20 LUVIAS LT 3000-XH		59	6J777901	MAGSEALED CAP
20 LUVIAS LT 3000-XH		60	6J777601	MAGSEALED PLATE
20 LUVIAS LT 3000-XH		61	6J791001	MAGSEALED PLATE"O"RING
20 LUVIAS LT 3000-XH		62	6J777802	MAGSEALED PLATE COLLAR
20 LUVIAS LT 3000-XH		63	6I639901	MAGSEALED PLATE WASHER
20 LUVIAS LT 3000-XH		64	6J776101	ONEWAY CLUTCH

