


BAITCASTING REEL **Millionaire 5H/5B/6H/6B**



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
<b>Millionaire 5B</b>					
1	6-353-0501	Handle nut plate screw	41	6-021-7201	Shield bush
2	6-040-3201	Handle nut plate	42	6-634-6101	Worm shield
3	6-341-5801	Handle nut	43	6-781-0201	Line guide
4	6-353-0701	Handle screw	44	6-121-4211	Line guide pin
5	6-745-8701	Handle	45	6-341-5901	Line guide nut
6	6-150-9001	Handle washer	46	6-735-3701	Spool
7	6-780-9801	Star drag	47	6-500-8011	Brake collar
8	6-780-9401	Right side cover	48	6-402-2001	Spool gear
9	6-353-1701	Right side cover screw	49	6-320-4202	Spool gear ret. ring
10	6-342-0801	Right spool cap	50	6-781-0311	Left side cover
11	6-373-7501	Ball bearing ret. washer	51	6-413-0001	Cog wheel
12	6-320-4101	Ball bearing retainer A	52	6-320-8002	Cog wheel ret. ring
13	6-634-6701	Ball bearing	53	6-352-4221	Left cover screw
14	6-320-6501	Ball bearing ret. ring	54	6-320-6501	Ball bearing ret. ring
15	6-374-9401	Drag washer A	55	6-634-6701	Ball bearing
16	6-143-9201	Drag coil spring	56	6-170-6701	"O" ring
17	6-374-9401	Drag washer B	57	6-320-7711	Ball bearing retainer B
18	6-374-9302	Drag washer C	58	6-373-7501	Ball bearing ret. washer
19	6-374-9501	Drag washer D	59	6-374-7221	Rubber washer
20	6-412-9901	Drive gear	60	6-342-1001	Left spool cap
21	6-374-9303	Gear shaft washer A	<b>Millionaire 5H Special Parts</b>		
22	6-725-4611	Gear shaft	20	6-413-0301	Drive gear
23	6-373-7611	Gear shaft washer B	29	6-750-2401	Pinion gear
24	6-780-9501	Set plate	50	6-781-0308	Left side cover
25	6-770-0301	Anti-reverse claw	<b>Millionaire 6B Special Parts</b>		
26	6-320-8002	Pinion yoke guide plate ret. ring	38	6-781-0801	Frame
27	6-780-9701	Pinion yoke guide plate	40	6-710-8211	Worm shaft
28	6-143-9311	Pinion yoke spring	42	6-634-6102	Worm shield
29	6-402-1901	Pinion gear	46	6-735-3901	Spool
30	6-635-9201	Pinion yoke	50	6-781-0309	Left side cover
31	6-780-9601	Clutch lever	<b>Millionaire 6H Special Parts</b>		
32	6-320-8202	Clutch ret. ring	20	6-413-0301	Drive gear
33	6-040-4701	Clutch stopper plate A	29	6-750-2401	Pinion gear
34	6-040-4801	Clutch stopper plate B	38	6-781-0801	Frame
35	6-142-8503	Set plate spring A	40	6-710-8211	Worm shaft
36	6-142-8502	Set plate spring B	42	6-634-6102	Worm shield
37	6-121-6801	Set plate screw	46	6-735-3901	Spool
38	6-780-9901	Frame	50	6-781-0310	Left side cover
39	6-151-4111	Worm shaft lock arm			
40	6-710-7711	Worm shaft			