


SPINNING REEL

REGAL-X3500T/4000T



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
2-9	F49-3701	Spool assembly	39	E00-7101	Anti-reverse pawl screw
1	F42-1906	Drag knob	40	E46-1302	Anti-reverse pawl
2	F37-3301	Drag washer retainer	41	E46-1201	Anti-reverse pawl spring B
3	F09-4901	Key washer	42	E03-7801	Bearing retainer screw
4	E13-6001	Drag washer	43	E32-7801	Anti-reverse cam spring
5	373-3603	Eared washer	44	F08-5124	Anti-reverse lever
6	F49-3801	Spool assembly	45	F13-1601	Oscillating gear collar
7	B07-5304	Click pawl	46	F24-6601	Oscillating gear
8	E40-3101	Click spring	47	E52-0201	Drive gear
9	320-5901	Click retainer	48	373-7805	Drive gear washer
10	F09-4701	Spool washer	49	631-6901	Ball bearing B
11	E46-2701	Click gear	50	F49-3601	Side cover
12	F48-0002	Main shaft	51	B83-5002	Side cover screw A
13	F09-1301	Oscillating slider	52	E15-8602	Side cover screw B
14	352-1502	Oscillating slider screw	53	F43-3501	Handle collar
15	340-6602	Rotor nut	54	B92-5011	Handle screw
16	F42-4205	Rotor	55	F50-4001	Handle assembly
17	B67-9308	Line roller screw	56	F40-1001	Bail holder washer
18	F45-2302	Bail arm			
19	B84-2102	Bail arm screw			
20	F44-6302	Line roller collar			
21	F44-6201	Line roller washer			
22	F47-3401	Line roller bushing			
23	F45-4902	Line roller			
24	F48-8901	Bail assembly			
25	E46-2101	Bail trip lever			
26	F12-8901	Bail spring			
27	F31-4305	Bail spring cover			
28	E24-8101	Bail spring cover screw			
29	F35-2405	Bail trip cover			
30	E46-2001	Anti-reverse pawl spring A			
31	F31-9801	Anti-reverse ratchet			
32	L03-6502	Ball bearing A			
33	F52-0101	Pinion gear			
34	F49-3501	Body assembly			

X4000T SPECIAL PARTS		
Key No.	Parts No.	Parts Name
2-9	F52-0001	Spool assembly
6	F52-0101	Spool assembly
16	F42-4305	Rotor assembly
24	F48-9601	Bail assembly
25	E46-3101	Bail trip lever
34	F49-3503	Body assembly
49	F49-3603	Side cover