




RYOGA SHRAPNEL C3000H

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
RYOGA SHRAPNEL C3000H		1	6H228203	LS RING
RYOGA SHRAPNEL C3000H		2	6H448501	PLATE RING
RYOGA SHRAPNEL C3000H		3	6J071801	LS PLATE
RYOGA SHRAPNEL C3000H		4	6H228501	GEAR RYOGA BJ C2020PE-H
RYOGA SHRAPNEL C3000H		5	6H228401	COLLAR
RYOGA SHRAPNEL C3000H		6	6H228601	SCREW
RYOGA SHRAPNEL C3000H		7	6H455301	O RING
RYOGA SHRAPNEL C3000H		8	63757404	WASHER (=63757400)
RYOGA SHRAPNEL C3000H		9	63757411	WASHER
RYOGA SHRAPNEL C3000H		10	6G185101	SPACER
RYOGA SHRAPNEL C3000H		11	6G511506	BALL BEARING
RYOGA SHRAPNEL C3000H		12	6F032201	RETAINER
RYOGA SHRAPNEL C3000H		13	6B339801	RETAINER
RYOGA SHRAPNEL C3000H		14	6H229401	SPOOL GEAR
RYOGA SHRAPNEL C3000H		15	6Z021659	SPOOL ASSY.
RYOGA SHRAPNEL C3000H		16	6J161802	BRAKE COLLAR(S)
RYOGA SHRAPNEL C3000H		17	6H358801	PIN
RYOGA SHRAPNEL C3000H		18	6G498506	BALL BEARING
RYOGA SHRAPNEL C3000H		19	6J055101	DRAG KNOB
RYOGA SHRAPNEL C3000H		20	6J031501	FRAME POST
RYOGA SHRAPNEL C3000H		21	6B864101	RETAINER
RYOGA SHRAPNEL C3000H		22	6H161201	SPACER (D)
RYOGA SHRAPNEL C3000H		23	6J031301	CLUTCH LEVER
RYOGA SHRAPNEL C3000H		24	6H161101	SPACER (E)
RYOGA SHRAPNEL C3000H		25	6H270401	STOPPER
RYOGA SHRAPNEL C3000H		26	6B339801	RETAINER
RYOGA SHRAPNEL C3000H		27	6H270010	RS COVER PLATE
RYOGA SHRAPNEL C3000H		28	6G159902	SCREW
RYOGA SHRAPNEL C3000H		29	6G523403	BALL BEARING
RYOGA SHRAPNEL C3000H		31	6H161301	CLUTCH TRIP LEVER
RYOGA SHRAPNEL C3000H		32	6H166401	CLUTCH PLATE
RYOGA SHRAPNEL C3000H		33	6H294101	SCREW
RYOGA SHRAPNEL C3000H		34	6J079301	KICK LEVER SP
RYOGA SHRAPNEL C3000H		35	6H441001	CLUTCH CAM
RYOGA SHRAPNEL C3000H		36	6J031401	CLUCH CAM PLATE(A)
RYOGA SHRAPNEL C3000H		37	6H159201	WASHER
RYOGA SHRAPNEL C3000H		38	6H159301	SCREW
RYOGA SHRAPNEL C3000H		39	6H266801	CLUTCH CAM PLATE (B)
RYOGA SHRAPNEL C3000H		40	6B032904	SCREW
RYOGA SHRAPNEL C3000H		41	6H159701	CLUTCH PLATE
RYOGA SHRAPNEL C3000H		42	6H226801	CLUTCH SPRING
RYOGA SHRAPNEL C3000H		43	6Z021657	PINION+DRIVE GEAR
RYOGA SHRAPNEL C3000H		44	6H160801	BEARING RETAINER
RYOGA SHRAPNEL C3000H		45	6F811804	PINION BEARING
RYOGA SHRAPNEL C3000H		46	6H159501	COLLAR
RYOGA SHRAPNEL C3000H		47	6H271009	RS PLATE
RYOGA SHRAPNEL C3000H		48	6H160302	RS PLATE SC(A)
RYOGA SHRAPNEL C3000H		49	6H160102	RS PLATE SC(B)
RYOGA SHRAPNEL C3000H		50	6H157002	O RING
RYOGA SHRAPNEL C3000H		51	6H160901	MECHANICAL BRAKE SPRING
RYOGA SHRAPNEL C3000H		52	6H225801	PINION SHAFT
RYOGA SHRAPNEL C3000H		53	6H161001	SPACER (F)
RYOGA SHRAPNEL C3000H		54	6B175503	SPACER
RYOGA SHRAPNEL C3000H		55	6J031001	MECHANICAL BRAKE KNOB
RYOGA SHRAPNEL C3000H		56	6B339801	RETAINER
RYOGA SHRAPNEL C3000H		57	6H226501	GEAR RYOGA BJ C2020PE-H
RYOGA SHRAPNEL C3000H		58	6G469007	BALL BEARING
RYOGA SHRAPNEL C3000H		59	6J031901	WORM SHAFT
RYOGA SHRAPNEL C3000H		60	6J031701	WORM SHEELD

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
RYOGA SHRAPNEL C3000H		61	6H166502	LEVEL WIND
RYOGA SHRAPNEL C3000H		62	6J032001	LEVEL WIND SC
RYOGA SHRAPNEL C3000H		63	6H168701	LINE GUIDE COLLAR
RYOGA SHRAPNEL C3000H		64	6H168601	LINE GUIDE PAWL
RYOGA SHRAPNEL C3000H		65	6G099801	WASHER (=6G099800)
RYOGA SHRAPNEL C3000H		66	6H158101	WORM SHAFT PLATE
RYOGA SHRAPNEL C3000H		67	6G159902	SCREW
RYOGA SHRAPNEL C3000H		68	6G469007	BALL BEARING
RYOGA SHRAPNEL C3000H		69	6B411711	WASHER
RYOGA SHRAPNEL C3000H		70	6B411701	WASHER (=6B411700)
RYOGA SHRAPNEL C3000H		71	63205901	RETAINER
RYOGA SHRAPNEL C3000H		72	6G099801	WASHER (=6G099800)
RYOGA SHRAPNEL C3000H		73	63208002	RETAINER(=6G994201)
RYOGA SHRAPNEL C3000H		74	6G538003	BALL BEARING
RYOGA SHRAPNEL C3000H		75	6H156501	GEAR SHAFT RETAINER
RYOGA SHRAPNEL C3000H		76	6E134501	SCREW
RYOGA SHRAPNEL C3000H		77	6H226301	DRIVE SHAFT
RYOGA SHRAPNEL C3000H		78	6H156901	GEAR SHAFT O RING
RYOGA SHRAPNEL C3000H		79	6H312501	CLUTCH WHEEL
RYOGA SHRAPNEL C3000H		80	6H359401	WASHER(B) (=6H156801)
RYOGA SHRAPNEL C3000H		81	6Z021657	PINION+DRIVE GEAR
RYOGA SHRAPNEL C3000H		82	6H227101	DRAG WASHER
RYOGA SHRAPNEL C3000H		83	6H359301	WASHER (=6H227201)
RYOGA SHRAPNEL C3000H		84	6H227301	DRAG LIP WASHER
RYOGA SHRAPNEL C3000H		85	6H384601	DRIVE COLLAR
RYOGA SHRAPNEL C3000H		86	6H157401	SPRING
RYOGA SHRAPNEL C3000H		87	6H157301	PIN
RYOGA SHRAPNEL C3000H		88	6H183401	DRIVE COLLAR O RING
RYOGA SHRAPNEL C3000H		89	6H384701	CLUTCH RING
RYOGA SHRAPNEL C3000H		90	6F552703	ROLLER CLUTCH
RYOGA SHRAPNEL C3000H		91	6G523403	BALL BEARING
RYOGA SHRAPNEL C3000H		92	63737810	WASHER (0.5MM)
RYOGA SHRAPNEL C3000H		93	6H158801	HOLDER
RYOGA SHRAPNEL C3000H		94	6H158701	CLICK LEAF SPRING
RYOGA SHRAPNEL C3000H		95	61508901	WASHER
RYOGA SHRAPNEL C3000H		96	6G694201	WASHER
RYOGA SHRAPNEL C3000H		97	6J041805	STAR DRAG
RYOGA SHRAPNEL C3000H		98	6H326801	HANDLE COLLAR (=6F850403)
RYOGA SHRAPNEL C3000H		99	6J032301	HANDLE ASSY.
RYOGA SHRAPNEL C3000H		100	6H166801	HANDLE NUT
RYOGA SHRAPNEL C3000H		101	6H166901	HANDLE LOCK PLATE
RYOGA SHRAPNEL C3000H		102	6H257001	SCREW
RYOGA SHRAPNEL C3000H		103	6J161801	BLEKE COLLAR
RYOGA SHRAPNEL C3000H		200	6B411703	WASHER (=6B411700)
RYOGA SHRAPNEL C3000H		201	6J070201	HANDLE KNOB
RYOGA SHRAPNEL C3000H		202	6G469007	BALL BEARING
RYOGA SHRAPNEL C3000H		203	6B679308	SCREW
RYOGA SHRAPNEL C3000H		204	6J084901	HANDLE KNOB CAP