




RYOGA SHRAPNEL C3000HL

Feel Alive.

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



審査	審査	照査	作成
----	----	----	----

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
RYOGA SHRAPNEL C3000HL		1	6H228203	RS RING
RYOGA SHRAPNEL C3000HL		2	6H448501	PLATE RING
RYOGA SHRAPNEL C3000HL		3	6J073001	RS PLATE
RYOGA SHRAPNEL C3000HL		4	6H228501	GEAR RYOGA BJ C2020PE-H
RYOGA SHRAPNEL C3000HL		5	6H228401	COLLAR
RYOGA SHRAPNEL C3000HL		6	6H228601	SCREW
RYOGA SHRAPNEL C3000HL		7	6H455301	O RING
RYOGA SHRAPNEL C3000HL		8	63757404	WASHER (=63757400)
RYOGA SHRAPNEL C3000HL		9	63757411	WASHER
RYOGA SHRAPNEL C3000HL		10	6G185101	SPACER
RYOGA SHRAPNEL C3000HL		11	6G511506	BALL BEARING
RYOGA SHRAPNEL C3000HL		12	6F032201	RETAINER
RYOGA SHRAPNEL C3000HL		13	6B339801	RETAINER
RYOGA SHRAPNEL C3000HL		14	6H229401	SPOOL GEAR
RYOGA SHRAPNEL C3000HL		15	6Z021659	SPOOL ASSY.
RYOGA SHRAPNEL C3000HL		16	6J161802	BRAKE COLLAR(S)
RYOGA SHRAPNEL C3000HL		17	6H358801	PIN
RYOGA SHRAPNEL C3000HL		18	6G498506	BALL BEARING
RYOGA SHRAPNEL C3000HL		19	6J072501	FRAME
RYOGA SHRAPNEL C3000HL		20	6J031501	FRAME POST
RYOGA SHRAPNEL C3000HL		21	6B864101	RETAINER
RYOGA SHRAPNEL C3000HL		22	6H161101	SPACER (E)
RYOGA SHRAPNEL C3000HL		23	6J031301	CLUTCH LEVER
RYOGA SHRAPNEL C3000HL		24	6H161201	SPACER (D)
RYOGA SHRAPNEL C3000HL		25	6H270401	STOPPER
RYOGA SHRAPNEL C3000HL		26	6B339801	RETAINER
RYOGA SHRAPNEL C3000HL		27	6H270011	LS COVER PLATE
RYOGA SHRAPNEL C3000HL		28	6G159902	SCREW
RYOGA SHRAPNEL C3000HL		29	6G523403	BALL BEARING
RYOGA SHRAPNEL C3000HL		31	6H193001	KICK LEVER
RYOGA SHRAPNEL C3000HL		32	6H192801	KICK LEVER PLATE
RYOGA SHRAPNEL C3000HL		33	6H294101	SCREW
RYOGA SHRAPNEL C3000HL		34	6J079401	KICK LEVER SP
RYOGA SHRAPNEL C3000HL		35	6H441101	CLUTCH CAM (=6H193101)
RYOGA SHRAPNEL C3000HL		36	6J072701	CLUTCH CAM PLATE(B)
RYOGA SHRAPNEL C3000HL		37	6H159201	WASHER
RYOGA SHRAPNEL C3000HL		38	6H159301	SCREW
RYOGA SHRAPNEL C3000HL		39	6H266801	CLUTCH CAM PLATE (B)
RYOGA SHRAPNEL C3000HL		40	6B032904	SCREW
RYOGA SHRAPNEL C3000HL		41	6H193601	CLUTCH PLATE
RYOGA SHRAPNEL C3000HL		42	6H226801	CLUTCH SPRING
RYOGA SHRAPNEL C3000HL		43	6Z021801	PINION+DRIVE GEAR
RYOGA SHRAPNEL C3000HL		44	6H160801	BEARING RETAINER
RYOGA SHRAPNEL C3000HL		45	6F811804	PINION BEARING
RYOGA SHRAPNEL C3000HL		46	6H159501	COLLAR
RYOGA SHRAPNEL C3000HL		47	6H272109	LS PLATE
RYOGA SHRAPNEL C3000HL		48	6H160302	LS PLATE SC(A)
RYOGA SHRAPNEL C3000HL		49	6H160102	LS PLATE SC(B)
RYOGA SHRAPNEL C3000HL		50	6H157002	O RING
RYOGA SHRAPNEL C3000HL		51	6H160901	MECHANICAL BRAKE SPRING
RYOGA SHRAPNEL C3000HL		52	6H225801	PINION SHAFT
RYOGA SHRAPNEL C3000HL		53	6H161001	SPACER (F)
RYOGA SHRAPNEL C3000HL		54	6B175503	SPACER
RYOGA SHRAPNEL C3000HL		55	6J031001	MECHANICAL BRAKE KNOB
RYOGA SHRAPNEL C3000HL		56	6B339801	RETAINER
RYOGA SHRAPNEL C3000HL		57	6H226501	GEAR RYOGA BJ C2020PE-H
RYOGA SHRAPNEL C3000HL		58	6G469007	BALL BEARING
RYOGA SHRAPNEL C3000HL		59	6J031901	WORM SHAFT
RYOGA SHRAPNEL C3000HL		60	6J031701	WORM SHEELD

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
RYOGA SHRAPNEL C3000HL		61	6H166502	LEVEL WIND
RYOGA SHRAPNEL C3000HL		62	6J032001	LEVEL WIND POST SC
RYOGA SHRAPNEL C3000HL		63	6H168701	LINE GUIDE COLLAR
RYOGA SHRAPNEL C3000HL		64	6H168601	LINE GUIDE PAWL
RYOGA SHRAPNEL C3000HL		65	6G099801	WASHER (=6G099800)
RYOGA SHRAPNEL C3000HL		66	6H193301	WASHER
RYOGA SHRAPNEL C3000HL		67	6G159902	SCREW
RYOGA SHRAPNEL C3000HL		68	6G469007	BALL BEARING
RYOGA SHRAPNEL C3000HL		69	6B411711	WASHER
RYOGA SHRAPNEL C3000HL		70	6B411701	WASHER (=6B411700)
RYOGA SHRAPNEL C3000HL		71	63205901	RETAINER
RYOGA SHRAPNEL C3000HL		72	6G099801	WASHER (=6G099800)
RYOGA SHRAPNEL C3000HL		73	63208002	RETAINER(=6G994201)
RYOGA SHRAPNEL C3000HL		74	6G538003	BALL BEARING
RYOGA SHRAPNEL C3000HL		75	6H156501	GEAR SHAFT RETAINER
RYOGA SHRAPNEL C3000HL		76	6E134501	SCREW
RYOGA SHRAPNEL C3000HL		77	6H226302	GEAR SHAFT
RYOGA SHRAPNEL C3000HL		78	6H156901	GEAR SHAFT O RING
RYOGA SHRAPNEL C3000HL		79	6H312501	CLUTCH WHEEL
RYOGA SHRAPNEL C3000HL		80	6H359401	WASHER(B) (=6H156801)
RYOGA SHRAPNEL C3000HL		81	6Z021801	PINION+DRIVE GEAR
RYOGA SHRAPNEL C3000HL		82	6H227101	DRAG WASHER
RYOGA SHRAPNEL C3000HL		83	6H359301	WASHER (=6H227201)
RYOGA SHRAPNEL C3000HL		84	6H227301	DRAG LIP WASHER
RYOGA SHRAPNEL C3000HL		85	6H384601	DRIVE COLLAR
RYOGA SHRAPNEL C3000HL		86	6H157401	SPRING
RYOGA SHRAPNEL C3000HL		87	6H157301	PIN
RYOGA SHRAPNEL C3000HL		88	6H183401	DRIVE COLLAR O RING
RYOGA SHRAPNEL C3000HL		89	6H384701	CLUTCH RING
RYOGA SHRAPNEL C3000HL		90	6F552703	ROLLER CLUTCH
RYOGA SHRAPNEL C3000HL		91	6G523403	BALL BEARING
RYOGA SHRAPNEL C3000HL		92	63737810	WASHER (0.5MM)
RYOGA SHRAPNEL C3000HL		93	6H158801	HOLDER
RYOGA SHRAPNEL C3000HL		94	6H158701	CLICK LEAF SPRING
RYOGA SHRAPNEL C3000HL		95	61508901	WASHER
RYOGA SHRAPNEL C3000HL		96	6G694201	WASHER
RYOGA SHRAPNEL C3000HL		97	6J041806	STAR DRAG
RYOGA SHRAPNEL C3000HL		98	6H326801	HANDLE COLLAR (=6F850403)
RYOGA SHRAPNEL C3000HL		99	6J032301	HANDLE ASSY.
RYOGA SHRAPNEL C3000HL		100	6H166801	HANDLE NUT
RYOGA SHRAPNEL C3000HL		101	6H166901	HANDLE LOCK PLATE
RYOGA SHRAPNEL C3000HL		102	6H257001	SCREW
RYOGA SHRAPNEL C3000HL		103	6J161801	BRAKE COLLAR(L)
RYOGA SHRAPNEL C3000HL		200	6B411703	WASHER (=6B411700)
RYOGA SHRAPNEL C3000HL		201	6J070201	HANDLE KNOB
RYOGA SHRAPNEL C3000HL		202	6G469007	BALL BEARING
RYOGA SHRAPNEL C3000HL		203	6B679308	SCREW
RYOGA SHRAPNEL C3000HL		204	6J084901	HANDLE KNOB CAP