




SALTIST 35H / 40H / 50H

SALTIST 35H/40H/50H

*Please order by parts number, not key number.

*Veuillez indiquer le numéro de la pièce (Non Key No.)



SALTIST 35H

KEY No.	Part No.	Part Name
1	753-0010	Frame assembly
2	725-1011	Click button
3	725-2010	Click plate
4	725-3010	Click collar
5	617-4030	Click button washer (A)
6	617-4010	Click button washer (A)
7	679-3010	Click pawl
8	731-6040	Click button washer (B)
9	201-4020	Click pawl retainer
10	744-8010	Click spring
11	757-4040	Bearing washer (A)
12	710-5011	Bearing washer (B)
13	703-3010	Bearing washer (C)
14	427-7011	Ball bearing (A)
15	709-5010	Bearing retainer (A)
16	716-9080	Frame plate
17	709-7010	Frame plate screw (B)
18	753-1011	Spool assembly
19	724-4010	Click gear
20	758-5010	Washer (A)
21	207-6010	Retainer (A)
22	744-3010	Brake collar (A)
23	751-0010	Set plate
24	700-7010	Ball bearing collar (A)
25	156-8030	Ball bearing (C)
26	751-8010	Bearing retainer (A)
27	717-9020	Yoke plate
28	709-8010	Washer (C)
29	706-8010	Screw (D)
30	754-4011	Drive shaft
31	575-3010	bearing
32	700-6010	Drive shaft retainer
33	208-0020	Retainer (B)
34	709-9010	Washer (B)

KEY No.	Part No.	Part Name
35	751-7010	Screw (B)
36	701-1011	Yoke
37	718-3010	Yoke spring
38	718-4010	Anti-reverse pawl pin
39	683-5011	Anti-reverse pawl
40	718-6020	Anti-reverse ratchet
41	718-8010	Drag washer (A)
42-D	735-1010	Pinion gear
42-P	753-4010	Drive gear
43	722-0010	Drag washer (B)
44	721-9010	Key washer (A)
45	722-0010	Drag washer (C)
46	722-1010	Eared washer
47	753-6010	Key washer (D)
48	725-6010	"O"ring (A)
49	706-5011	Pin
50	751-1010	Right side plate
51	633-3010	Roller clutch
52	749-7010	Clutch lever (A)
53	706-9010	Clutch lever washer (A)
54	711-1010	Clutch lever washer (B)
55	700-1011	Clutch cam plate
56	707-5010	Clutch cam
57	207-6010	Clutch cam retainer
58	706-4011	Clutch cam spring
59	753-9010	bearing (D)
60	720-1010	Bearing retainer (B)
61	720-2010	"O"ring (B)
62	754-0010	Cast control cap
63	175-5033	Washer (E)
64	725-0010	Washer (F)
65-1	720-7010	Screw (G)
65-2	720-7020	Screw (F)
66	688-8010	"O"ring (C)

KEY No.	Part No.	Part Name
67	754-1010	Screw (F)
68	720-9010	Screw (A)
69	610-7011	Gear shaft collar
70	709-1051	Washer (G)
71	729-6010	"O"ring (D)
72	523-4030	Ball bearing (E)
73	709-1031	Washer (H)
74	709-2010	Click leaf spring holder
75	715-6010	Click leaf spring (B)
76	721-0010	Drag spring washer
77	694-2010	Washer (I)
78	721-5010	Nut
79	711-7010	Spring
80	721-1020	Star drag
81	715-1011	Handle collar (A)
82	711-9011	Handle collar (B)
83	754-2010	Handle assembly
84	220-3062	Handle nut
85	218-2011	Handle nut screw
86	742-0040	Clamp bolt
87	624-4020	Rod clamp
88	600-8011	Clamp nut
89	352-7020	Brake collar (B)

SALTIST40H

Key No.	Part No.	Part Name
1	754-5010	Frame assembly
16	716-9090	Frame plate
18	754-6011	Spool assembly
50	751-1020	Right side plate

SALTIST 50H

Key No.	Part No.	Part Name
1	755-1010	Frame assembly
16	716-9100	Frame plate
18	755-2011	Spool assembly
50	751-1030	Right side plate