


SPINNING REEL

STTB4000LT

*Please order by parts number, not key number.



Key No Part No Description

1	J29-0601	DRAG KNOB
2	F71-0001	DRAG RING
3	F89-5301	DRAG RACHET
4	J56-1901	DRAG WASHER
5	F62-7301	DRAG LIP WASHER
6	F62-7201	DRAG DISC WASHER
7	H62-4801	DRAG COLLAR
2~8	J78-2701	SPOOL ASSEMBLY
9	G47-2401	SPOOL METAL RING
10	E30-6801	SPOOL METAL BALL BEARING
11	N/A	SPOOL METAL COLLAR
12	H80-6301	SPOOL WASHER
13	H41-6001	CLICK HOLDER
14	H88-3701	CLICK LEAF SPRING
15	H61-5003	SPOOL METAL
16	G37-5001	SPOOL METAL PIN
17	H98-6901	ROTOR NUT PACKING
18	H96-1101	ROTOR NUT
19	H02-2701	ROTOR NUT SCREW
20	J56-7508	ROTOR
21	H41-3601	KICK LEVER SPRING
22	J56-7601	KICK LEVER
23	H41-7701	KICK LEVE SCREW
24	H57-2001	ARM LEVER SHAFT
25	H57-6101	ARM LEVER SHAFT PLATE
26	H41-4201	ARM LEVER SPRING
27	J08-9401	ARM LEVER SPRING HOLDER
28	J56-7801	ARM LEVER SPRING COVER
29	G27-0801	ARM LEVER SPRING COVER SCREW
30	H72-8912	ARM LEVER
31	H96-2401	ARM LEVER SCREW COLLAR
32	G20-5001	ARM LEVER SCREW
33	G19-5602	ROLLER SCREW
34	G19-5501	LINE ROLLAR COLLAR(A)
35	G22-0701	LINE ROLLAR COLLAR(B)
36	J08-9902	LINE ROLLAR
37	G87-4201	LINE ROLLAR COLLAR(C)
38	J78-2301	BAIL ASSEMBLY
39	G20-5001	BAIL HOLDER SCREW
40	J00-1601	MAGSHIELD SCREW
41	J68-8201	MAGSHIELD ASSEMBLY

Key No Part No Description

42	J35-4801	MAGSHIELD ORING
43	N/A	MAGSHIELD WASHER
44	J56-0901	MAGSHIELD CAP
45	J63-9900	ONEWAY CLUCH WASHER
46	J38-8401	ONEWAY CLUCH
47	J00-1403	CLUCH RING
48	J00-0901	PINION BALL BEARING PLATE SCREW
49	H41-1501	PINION BALL BEARING PLATE
50	G53-5104	PINION BALL BEARING(A)
51	375-8502	PINION BALL BEARING WASHER
52	Z02-4106	PINON+DRIVE GEAR SET
53	H93-1701	PINION BALL BEARING(B) SPRING WASHER
54	G46-6202	PINION BALL BEARING(B)
55	J00-1101	BAIL KICK COLAR
56	G94-0402	BAIL KICK COLAR SCREW
57	J46-1902	BODY
58	J14-0801	MAIN SHAFT
59	J08-4802	OSCILLATING POST(A)
60	H61-4301	OSCILLATING POST(B)
61	H59-5501	STOPPER CAM
62	H59-5401	STOPPER LEVER
63	H69-7801	STOPPER LEAF SPRING
64	J36-3701	REAR CAP
65	J00-1801	REAR CAP SCREW
66	H59-5701	OSCILLATING GEAR WASHER
67	H61-3901	OSCILLATING GEAR
68	G46-6001	OSCILLATING GEAR ORING
69	H12-9201	OSCILLATING GEAR BALL BEARING WASHER
70	G46-9005	OSCILLATING GEAR BALL BEARING
71	G94-0402	OSCILLATING GEAR SCREW
72	G67-0501	DRIVE GEAR ORING
73	375-8502	DRIVE BALL BEARING WASHER
74	G46-7302	DRIVE BALL BEARING(A)
75	J41-9302	BODY COVER
76	G33-2906	BODY COVER SCREW
77	J13-0201	HANDLE PACKING
78	J46-1501	HANDLE ASSEMBLY
79	G52-2706	DRIVE BALL BEARING(B)
80	G47-2401	DRIVE BALL BEARING PACKING
81	G16-2401	HANDLE CAP ORING
82	J41-8101	HANDLE CAP