




# SEAGATE HYPER 4500

Feel Alive.

Please quote by part number, not key number when ordering.  
spares@daiwaaustralia.com.au PH: (02) 8644 8644

SEAGATE HYPER  
4500



11111111

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
SEAGATE HYPER 4500		1	6H395302	DRAG KNOB
SEAGATE HYPER 4500		2	6F710001	DRAG WASHER RETAINER
SEAGATE HYPER 4500		3	6G165602	DRAG KNOB CLICK PLATE
SEAGATE HYPER 4500		4	6H247201	DRAG WASHER
SEAGATE HYPER 4500		5	6G165902	EARED WASHER
SEAGATE HYPER 4500		6	6G162702	DRAG DISC WASHER
SEAGATE HYPER 4500		2-7	6H970901	SPOOL ASSEMBLY
SEAGATE HYPER 4500		8	6G163201	"O" RING
SEAGATE HYPER 4500		9	6F137500	WASHER (A)
SEAGATE HYPER 4500		10	6E122301	CLICK LEAF SPRING HOLDER
SEAGATE HYPER 4500		11	6B747701	SPOOL CLICK LEAF SPRING
SEAGATE HYPER 4500		12	6G203801	SPOOL METAL
SEAGATE HYPER 4500		13	6G224101	PIN(A)
SEAGATE HYPER 4500		14	6H270301	ROTOR NUT
SEAGATE HYPER 4500		15	6G162501	PACKING
SEAGATE HYPER 4500		16	6G466201	BALL BEARING(A)
SEAGATE HYPER 4500		17	6H245005	ROTOR
SEAGATE HYPER 4500		18	6G627701	SCREW(A)
SEAGATE HYPER 4500		19	6H245601	BAIL HOLDER NUT
SEAGATE HYPER 4500		20	6H245701	BAIL ASSEMBLY
SEAGATE HYPER 4500		21	63516105	SCREW(B)
SEAGATE HYPER 4500		22	6H035502	COLLAR (A)
SEAGATE HYPER 4500		23	6H246101	LINE ROLLER
SEAGATE HYPER 4500		24	6G740601	COLLAR (B)
SEAGATE HYPER 4500		25	6G370905	BALL BEARING(B)
SEAGATE HYPER 4500		26	6G740501	PACKING
SEAGATE HYPER 4500		27	6H271201	COLLAR (C)
SEAGATE HYPER 4500		28	6H245404	BAIL ARM
SEAGATE HYPER 4500		29	6G455601	SCREW (C)
SEAGATE HYPER 4500		30	6F608901	SCREW(D)
SEAGATE HYPER 4500		31	6H245301	BAIL SPRING SHAFT
SEAGATE HYPER 4500		32	6H345301	BAIL SPRING
SEAGATE HYPER 4500		33	6H270501	BAIL SPRING HOLDER
SEAGATE HYPER 4500		34	6H245501	BAIL SPRING COVER
SEAGATE HYPER 4500		35	6G205101	SCREW(E)
SEAGATE HYPER 4500		36	6H264401	BAIL TRIP LEVER SPRING
SEAGATE HYPER 4500		37	6H245901	BAIL TRIP LEVER
SEAGATE HYPER 4500		38	6G194301	BRAKE SHOE
SEAGATE HYPER 4500		39	63753000	WASHER (B)
SEAGATE HYPER 4500		40	6G193701	SCREW(F)
SEAGATE HYPER 4500		41	6H244201	ROLLER CLUTCH RETAINER
SEAGATE HYPER 4500		42	63516101	SCREW(G)
SEAGATE HYPER 4500		43	6H244101	PACKING
SEAGATE HYPER 4500		44	6H244001	CLUTCH CAM RETAINER
SEAGATE HYPER 4500		45	6H247601	CLUTCH CAM
SEAGATE HYPER 4500		46	6G314501	ROLLER CLUTCH
SEAGATE HYPER 4500		47	6H172703	SPACING SLEEVE
SEAGATE HYPER 4500		48	6H244501	BEARING RETAINER(A)
SEAGATE HYPER 4500		49	6G557101	SCREW(H)
SEAGATE HYPER 4500		50	6G472501	BALL BEARING(C)
SEAGATE HYPER 4500		51	6H243901	COLLAR (D)
SEAGATE HYPER 4500		52	6E262701	RATCHET
SEAGATE HYPER 4500		53	6H243801	PINION GEAR
SEAGATE HYPER 4500		54	6H243701	COLLAR (E)
SEAGATE HYPER 4500		55	6H970601	BODY
SEAGATE HYPER 4500		56	6H243401	MAIN SHAFT
SEAGATE HYPER 4500		57	6G162801	PIN(B)
SEAGATE HYPER 4500		58	6H243101	OSCILLATING GEAR(A)
SEAGATE HYPER 4500		59	6H243001	OSCILLATING GEAR(B)
SEAGATE HYPER 4500		60	6G157401	OSCILLATING GEAR SPRING

