




Please quote by part number, not key number when ordering
 spares@daiwaaustralia.com.au PH: 02 8644 8644

2017 SOL III LT 6000D-H



- S 39206D
- S 39406D
- S 39506D
- S 39706D
- S 39806D
- S 39906D



Please quote by part number, not key number when ordering
 spares@daiwaaustralia.com.au PH: 02 8644 8644

2017 SOL III LT 6000D-H

Key No.	Part Number	Description	Key No.	Part Number	Description
1	6J579901	DRAG KNOB	45	6H431201	BAIL HOLDER SCREW
2	61704101	DRAG RING	46	6J429301	MAGSEALED PLATE SCREW
3	6J577501	DRAG DISC WASHER	47	6J428901	MAGSEALED PLATE
4	6J679001	ATD DRAG WASHER	48	6J212901	MAGSEALED PLATE ORING
5	6J577301	DRAG LIP WASHER	49	6J428801	MAGSEALED CAP
6	6J577401	DRAG DISC WASHER	50	6J431601	ONEWAY CLUTCH WASHER
7	-	-	51	6J309101	ONEWAY CLUTCH
8	6E306801	DRAG BALL BEARING	52	6G997301	PINION BEARING PLATE SCREW
9	6J568601	LINE STOPPER PLATE	53	6J397301	CLUTCH RING
10	6J558001	LINE STOPPER	54	-	-
11	6J314801	LINE STOPPER SPRING	55	6J020801	PINION BEARING PLATE
12	6J671901	SPOOL ASSEMBLY (2~12)	56	6G522802	PINION BALL BEARING (A)
13	6J576700	SPOOL WASHER	57	63712800	PINION BEARING WASHER (A)
14	6J558202	SPOOL METAL SCREW	58	6Z023712	PINION + DRIVE GEAR SET
15	6J576601	SPOOL METAL	59	6G572501	PINION BEARING SPRING WASHER (B)
16	6G756301	SPOOL METAL BEARING	60	6G467102	PINION BALL BEARING (B)
17	6J602101	CLICK HOLDER WASHER	61	-	-
18	6J525101	CLICK LEAF SPRING	62	6J428101	PINION COLLAR
19	6J576501	CLICK HOLDER	63	6J611001	BODY ASSY
20	6H995201	ROTOR NUT PACKING	64	6J576101	MAIN SHAFT
21	6H995101	ROTOR NUT	65	6J084806	OSCILLATING POST
22	6H022701	ROTOR NUT SCREW	66	6J020501	STOPPER CAM
23	6H994332	ROTOR	67	6H595401	STOPPER LEVER
24	6H413601	KICK LEVER SPRING	68	6H697801	STOPPER CAM LEAF SPRING
25	6H994401	KICK LEVER ASSY	69	6J429401	REAR CAP
26	6H417701	KICK LEVER SCREW	70	6J389001	REAR CAP SCREW
27	6H640601	ARM LEVER SHAFT	71	6J496901	OSCILLATING GEAR WASHER
28	6H576101	ARM LEVER SHAFT PLATE	72	6J575901	OSCILLATING GEAR
29	6H640701	ARM LEVER SHAFT SPRING	73	6B853101	OSCILLATING GEAR ORING
30	6J089401	ARM LEVER SHAFT HOLDER	74	6G522100	OSCILLATING GEAR BALL BEARING WASHER
31	6H994601	ARM LEVER SP COVER	75	6G467105	OSCILLATING GEAR BALL BEARING
32	6H431301	ARM LEVER SP COVER SCREW	76	6H463401	OSCILLATING GEAR BALL BEARING SCREW
33	6H960124	ARM LEVER	77	6G645301	DRIVE GEAR ORING
34	6H962401	ARM LEVER COLLAR	78	63737800	DRIVE WASHER
35	6H431201	ARM LEVER SCREW	79	6G523406	DRIVE GEAR BALL BEARING (A)
36	6H697701	ROLLER SCREW	80	6J612001	BODY COVER ASSY
37	6H744001	ROLLER MAGSEALED (A)	81	6J389801	BODY COVER SCREW
38	6G686903	ROLLER BALL BEARING	82	6H730801	HANDLE CAP PACKING
39	6H743901	ROLLER BALL BEARING COLLAR (A)	83	6J611401	HANDLE ASSY
40	6H743801	LINE ROLLER	84	6G431007	DRIVE GEAR BALL BEARING (B)
41	6H743701	ROLLER BALL BEARING COLLAR (B)	85	6G525101	DRIVE BEARING RING
42	6H743401	ROLLER MAGSEALED (B)	86	6G672401	HANDLE CAP ORING
43	6B411700	ROLLER MAGSEALED WASHER	87	6J429901	HANDLE CAP
44	6J576402	BAIL ASSY			